









Original	Replacement	Original	Replacement
	Power		Power
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	Source		AV
	ATV/DTV/Content Menu		Smart
	Vol+		Vol +
	Vol-		Vol -
	P+		Ch +
	P-		Ch -

Original	Replacement	Original	Replacement
	Mute		Mute
	Guide/Top		Media
	Exit/Return		Exit
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	OK		Ok
	Menu/DVD		Menu
	Tv/FAV/Radio/Set		TV/R
	Red		Red
	Green		Green
	Yellow		Yellow
	Blue		Blue
	[<>]		Format
	<[/]>		3D
	Subtitle		Subt









































































Original	Replacement	Original	Replacement
Text	Text		
II/II>/[▼]	Pause		
[i+]/[≡i]	Info		
O)I/II	Dual		
Stop	Stop		
Play/[≡o]	Play		
Eject	Eject		
I<</[≡?]	I<<		
<</[≡+]	<<		
>>/[≡♦]	>>		
>>I/[O]/[≡X]	>>I		
AD	Shift + Subt		
Audio	Shift + Dual		





Original		Replacement		Original		Replacement	
	←[/]→		3D		Menu/DVD		Menu
	Power		Power		Tv/FAV/Radio/Set		TV/R
	1		1		Guide/Top		Guide
	2		2		[<>]		Format
	3		3		Text		Text
	4		4		Subtitle		Subt
	5		5		O)/II		Dual
	6		6		[i+]/[≡i]		Info
	7		7		OK		Ok
	8		8		Up		Up
	9		9		Down		Down
	0		0		Right		Right
	Source		AV		Left		Left
	Mute		Mute		/II>/[▼]		Pause
	Vol+		Vol +		Play/[≡o]		Play
	Vol-		Vol -		Stop		Stop
	Exit/Return		Exit		Eject		Eject





























































Original	Replacement	Original	Replacement
 <</[≡?]	 <<		
 <</[≡+]	 <<		
 >>/[≡◇]	 >>		
 >> /[O]/[≡X]	 >>		
 Audio	 +  Shift + Dual		





Original	Replacement	Original	Replacement
	Power		Power
	←[/]→		3D
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	Source		AV
	ATV/DTV/Content Menu		Smart
	Vol+		Vol +
	Vol-		Vol -
	P+		Ch +

Original	Replacement	Original	Replacement
	P-		Ch -
	Mute		Mute
	Guide/Top		Guide
	Exit/Return		Exit
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	OK		Ok
	Menu/DVD		Menu
	Tv/FAV/Radio/Set		TV/R
	Red		Red
	Green		Green
	Yellow		Yellow
	Blue		Blue
	Text		Text
	[<>]		Format





Original	Replacement
[i+]/[≡i]	DISPLAY INFO Info
II/II>/[▼]	II Pause
SUBTITLE	AD SUBT Subt
O)I/II	SOUND DUAL Dual
Play/[≡o]	PLAY MODE ▶ Play
CD/I	CD/I ■ Stop
SUBTITLE	ZOOM ▲ Eject
I<</[≡?]	I<< I<<
<</[≡+]	<< <<
>>/[≡◇]	>> >>
>>I/[O]/[≡X]	>>I >>I
AUDIO TEXT Audio	SHIFT + SOUND DUAL Shift + Dual
AD	SHIFT + AD SUBT Shift + Subt

Original	Replacement

