







































































Original	Replacement	Original	Replacement
 Power	 Power	 9	 9
 [≡?]	 Dual	 0	 0
 [≡♦]/[+]/Wide	 3D	 PP	 Pre Ch
 [≡i]/Guide	 Guide	 [≡]	 Text
 [i]/Info	 Info	 Vol+	 Vol +
 [≡o]	 Subt	 Vol-	 Vol -
 [≡+]/[X]	 Format	 Mute	 Mute
 [≡x]/[·]	 Options	 P/CH+	 Ch +
 [/≡]/[*]	 Smart	 P/CH-	 Ch -
 1	 1	 P<P/Swap	 Back
 2	 2	 TV/DTV	 TV/R
 3	 3	 AV/Source	 AV
 4	 4	 Menu	 Menu
 5	 5	 -/--	 Shift + Guide
 6	 6	 Exit	 Exit
 7	 7	 Up	 Up
 8	 8	 Down	 Down



