

































Original	Replacement
 1	 1
 AUX	 AV
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7/P	 7
 8	 8
 9	 9
 0	 0
 10/Return	 Shift + Guide
 +10/+100	 Pre Ch
 Play/TA/News/Info	 Play
 Pause/PTY Search	 Pause
Stop/Display	Stop
>>I/PTY+	>>I

Original	Replacement
 I<</PTY-	 I<<
 FM/AM	 Smart
 FM Mode	 Media
 Pause FM/AM	 Ok
 Play FM/AM	 Up
 Stop FM/AM	 Down
 >>I FM/AM	 Right
 I<<FM/AM	 Left
 Test	 Options
 Effect	 Dual
 Level- SURR L	 Vol -
 Level+ SURR L	 Vol +
 1 FM/AM	 Shift + 1
 2 FM/AM	 Shift + 2
 3 FM/AM	 Shift + 3
4 FM/AM	Shift + 4
5 FM/AM	Shift + 5





Original	Replacement
6 FM/AM	+  Shift + 6
7 FM/AM	+  Shift + 7
8 FM/AM	+  Shift + 8
9 FM/AM	+  Shift + 9
10 FM/AM	Guide
+10 FM/AM	+  Shift + Pre Ch
Level+ SURR R	Ch +
Level - SURR R	Ch -
Level+ Center	>>
Level- Center	<<
Level+ SUBWFR	TV/R
Level- SUBWFR	3D
Level+ Front L	Green
Level- Front L	Red
Level+ Front R	Blue
Level- Front R	Yellow

Original	Replacement









































































	Original	Replacement	Original	Replacement
	Up			
	Down			
	Right			
	Left			
	Enter			
	Menu			
	Pause/PTY Search			
	Play/TA/News/Info			
	Stop/Display			
	I<</PTY-			
	>>I/PTY+			
	Play VCR			
	Pause VCR			
	Stop VCR			
	>>I VCR			
	I<< VCR			
	Rec Pause VCR			





Original	Replacement
 Audio Standby	 Power
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7/P	 7
 Tv CH+	 Ch +
 Tv CH-	 Ch -
 VCR CH+	 Shift + Ch +
 VCR CH-	 Shift + Ch -
 TV Standby	 Red
 VCR Standby	 Green
 DVD Standby	 Yellow
 Play/TA/News/Info	 Play
 Pause/PTY Search	 Pause

Original	Replacement
 Stop/Display	 Stop
 Sleep	 Sleep
 >>I/PTY+	 >>I
 I<</PTY-	 I<<
 Tv/Video	 TV/R
 Analog/Digital	 Media
 Dimmer	 3D
 Surround	 Dual
 DSP	 AV
 Surround DSP	 Subt
 Vol+	 Vol +
 Vol-	 Vol -
 Tv Vol+	 Right
 Tv Vol-	 Left
 Muting	 Mute
 VCR	 Back
 FM/AM	 Options





Original

Replacement

Original

Replacement



Original	Replacement	Original	Replacement
 FM/Mode	 Text		





Original	Replacement
Rec Pause	Rec
Pause	Pause
Stop	Stop
Play	Play
>>I	>>I
I<<	I<<
TV Sound	Smart
1 TV Sound	1
2 TV Sound	2
3 TV Sound	3
4 TV Sound	4
5 TV Sound	5
6 TV Sound	6
7 TV Sound	7
8 TV Sound	8
9 TV Sound	9
0 TV Sound	0

Original	Replacement
10 TV Sound	Guide
+10 TV Sound	Pre Ch

