





































































Originalfernbedienung Ersatzfernbedienung

	Standby/On		Power
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	Tv/DVD		TV/R
	Open/Close		Eject
	DTV/Analog		Smart
	Input Sel		AV
	Copy		Options
	Pause		Pause

Originalfernbedienung Ersatzfernbedienung

	I <<		I <<
	>> I		>> I
	Play		Play
	Stop		Stop
	<<		<<
	>>		>>
	Mute		Mute
	Prog+		Ch +
	Prog-		Ch -
	Vol+		Vol +
	Vol-		Vol -
	Menu		Menu
	Return		Back
	Exit		Exit
	Title List/Disc Menu		Media
	Play List/Title Menu		Shift + Menu
	Red		Red





Originalfernbedienung Ersatzfernbedienung

	Green		Green
	Yellow		Yellow
	Blue		Blue
	Guide		Guide
	Info		Info
	Subtitle		Subt
	Text		Text
	Tv/Radio		Sleep
	FAV List		Pre Ch
	Marker		Shift + Options
	Rec		Rec
	Audio		Dual
	Rec Mode		Shift + Rec
	Rec		Format
	Repeat		Shift + Text
	OK		Ok
	Up		Up

Originalfernbedienung Ersatzfernbedienung

	Down		Down
	Right		Right
	Left		Left
	USB		Shift + Media
	Timer		Shift + AV
	HDD		Shift + Smart





Originalfernbedienung Ersatzfernbedienung

































Input Sel	AV	AV
1	1	1
2	2	2
3	3	3
4	4	4
5	5	5
6	6	6
7	7	7
8	8	8
9	9	9
0	0	0
Prog+	Ch +	Ch +
Prog-	Ch -	Ch -
Standby/On TV	Power	Power
Mute Tv	Mute	Mute
Tv Vol+	Vol +	Vol +
Tv Vol-	Vol -	Vol -

Originalfernbedienung Ersatzfernbedienung







































Originalfernbedienung Ersatzfernbedienung

	Standby/On		Power
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	Tv/DVD		TV/R
	Open/Close		Eject
	DTV/Analog		Smart
	Input Sel		AV
	Copy		Options
	Pause		Pause











Originalfernbedienung Ersatzfernbedienung

	<<		<<
	>>		>>
	Play		Play
	Stop		Stop
	<<		<<
	>>		>>
	Prog+		Ch +
	Prog-		Ch -
	Menu		Menu
	Return		Back
	Exit		Exit
	Title List/Disc Menu		Media
	Play List/Title Menu		Shift + Menu
	Red		Red
	Green		Green
	Yellow		Yellow
	Blue		Blue











Originalfernbedienung Ersatzfernbedienung

	Guide		Guide
	Info		Info
	Subtitle		Subt
	Text		Text
	Tv/Radio		D. Menu
	FAV List		Pre Ch
	Marker		Shift + Options
	Rec		Rec
	Audio		Dual
	Rec Mode		Shift + Rec
	Rec		Format
	Repeat		Shift + Text
	OK		Ok
	Up		Up
	Down		Down
	Right		Right
	Left		Left

Originalfernbedienung Ersatzfernbedienung

	USB		Shift + Media
	Timer		Shift + AV
	HDD		Shift + Smart

