








































Originalfernbedienung Ersatzfernbedienung

	Power		Power
	TV		TV/Radio /
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	FAV CH		Fav / Marker / PC
	0		0
	PRE-CH		Back / Return
	Info		Info / Angle
	Menu		Menu / Home
	Guide		Guide / EPG / -/--

Originalfernbedienung Ersatzfernbedienung

	Tools		Setup / OPT /
	Return		Shift + Back / Return
	Up		Up
	Left		Left
	Enter		OK
	Right		Right
	CH List		Smart / List
	Down		Down
	Exit		Exit / Cancel / Clear
	Red		Red / Netflix / Search
	Green		Green / APP / Repeat
	Yellow		Yellow / YouTube / Repeat
	Blue		Blue / Prime Video / Random
	Vol+		Vol+
	Source		AV / Input / RDS
	PR+		CH+ / Page+
	Vol-		Vol-



