





































Originalfernbedienung Ersatzfernbedienung

	Power		Power
	Mute		Mute
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0/AV		0
	EPG/←		Guide
	Media		Media
	PIP/[]		3D
	Text/Disc-M		Text
	Menu		Menu



































Originalfernbedienung Ersatzfernbedienung

	End		Exit
	Info		Info
	Up		Up
	OK		Ok
	Down		Down
	Right		Right
	Left		Left
	Red		Red
	Green		Green
	Yellow		Yellow
	Blue/Marker		Blue
	Vol+		Vol +
	Vol-		Vol -
	P+		Ch +
	P-		Ch -
	<<		<<
	Play		Play







































Originalfernbedienung Ersatzfernbedienung

	Power		Power
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0/AV		0
	EPG/←		Guide
	Media		Media
	PIP/[]		3D
	Text/Disc-M		Text
	Menu		Menu
	End		Exit

Originalfernbedienung Ersatzfernbedienung

	Info		Info
	OK		Ok
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	P+		Ch +
	P-		Ch -
	Red		Red
	Green		Green
	Yellow		Yellow
	Blue/Marker		Blue
	<<		<<
	Play		Play
	>>		>>
	Pause		Pause
	Stop		Stop







































Originalfernbedienung	Ersatzfernbedienung	Originalfernbedienung	Ersatzfernbedienung
	Rec		Rec
	→[]←/Zoom		Format
	O/Pop-Up-M		D. Menu







































Originalfernbedienung Ersatzfernbedienung

	Power		Power
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0/AV		0
	EPG/←		Guide
	Media		Media
	PIP/[]		3D
	Text/Disc-M		Text
	Menu		Menu
	End		Exit







Originalfernbedienung Ersatzfernbedienung

	Info		Info
	Red		Red
	Green		Green
	Yellow		Yellow
	Blue/Marker		Blue
	<<		<<
	Play		Play
	>>		>>
	Rec		Rec
	Pause		Pause
	Stop		Stop
	O/Pop-Up-M		D. Menu
	→[]←/Zoom		Format
	Up		Up
	OK		Ok
	Down		Down
	Right		Right





Originalfernbedienung Ersatzfernbedienung

	Left		Left
	P+		Ch +
	P-		Ch -

Originalfernbedienung Ersatzfernbedienung

