



































**Originalfernbedienung    Ersatzfernbedienung**

	Power		Power
	3D		3D
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	ECO		Shift + 3D
	Source		AV
	Vol +		Vol +
	Vol -		Vol -
	Mute		Mute

**Originalfernbedienung    Ersatzfernbedienung**

	Info		Info
	P +		Ch +
	P -		Ch -
	W		Shift + Smart
	Smart TV		Smart
	@		Media
	Menu		Menu
	Up		Up
	Down		Down
	Right / Zoom +		Right
	Left / Zoom -		Left
	OK		Ok
	Back		Back
	Exit		Exit
	Option		Options
	USB		Shift + Media
	TV		TV/R



