







































































Originalfernbedienung Ersatzfernbedienung

	Power		Power
	Tv/DTV		TV/R
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	[i+]		Info
	Mute		Mute
	I-II		Dual
	Home Menu		Menu
	Exit		Exit

Originalfernbedienung Ersatzfernbedienung

	EPG		Guide
	Return		Back
	Vol+		Vol +
	Vol-		Vol -
	PR+		Ch +
	PR-		Ch -
	Up		Up
	Down		Down
	Left		Left
	Right		Right
	OK		Ok
	Red		Red
	Green		Green
	Yellow		Yellow
	Blue		Blue
	[...]		Subt
	[≡?]		Eject



