































**Originalfernbedienung Ersatzfernbedienung**

	Power		Power
	Disc		Media
	Subtitle		Subt
	Angle		TV/R
	Zoom		Eject
	Audio		Dual
	Disc Menu		D. Menu
	Setup		Options
	Return/Title		Back
	Display		Info
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	OK		Ok
	I<<		I<<
	Play		Play

**Originalfernbedienung Ersatzfernbedienung**

	>>I		>>I
	Pause		Pause
	Stop		Stop
	Vol+		Vol +
	Vol-		Vol -
	Mute		Mute
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	Program		Sleep





Originalfernbedienung	Ersatzfernbedienung	Originalfernbedienung	Ersatzfernbedienung
	Repeat		Text
	Surr.		Red
	Sound	 + 	Shift + Dual
	Vocal		Yellow
	Karaoke		Blue



























**Originalfernbedienung    Ersatzfernbedienung**

	Power		Power
	Tuner		Media
	Display		Info
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	OK		Ok
	I<<		I<<
	Play		Play
	>>I		>>I
	Stop		Stop
	Vol+		Vol +
	Vol-		Vol -
	Mute		Mute
	1		1
	2		2








**Originalfernbedienung    Ersatzfernbedienung**

	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	Program		Sleep
	Surr.		Red
	Sound		Dual



























**Originalfernbedienung Ersatzfernbedienung**

	Power		Power
	TV		Media
	Setup		Options
	Display		Info
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	OK		Ok
	I<<		I<<
	Play		Play
	>>I		>>I
	Stop		Stop
	Tv Vol+		Vol +
	Tv Vol-		Vol -
	Mute		Mute
	1		1

**Originalfernbedienung Ersatzfernbedienung**

	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	Surr.		Red
	Sound		Dual



























**Originalfernbedienung    Ersatzfernbedienung**

	Power		Power
	AUX/DI		Media
	Display		Info
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	OK		Ok
	I<<<		I<<<
	Play		Play
	>>>I		>>>I
	Stop		Stop
	Vol+		Vol +
	Vol-		Vol -
	Mute		Mute
	1		1
	2		2

**Originalfernbedienung    Ersatzfernbedienung**

	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	Program		Sleep
	Surr.		Red
	Sound		Dual

