



































































**Originalfernbedienung    Ersatzfernbedienung**

	Power		Power
	[i]/Info		Info
	HDMI Control		Options
	Sleep		Sleep
	Screen		Format
	Source		AV
	Presets		3D
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	Return		Back

**Originalfernbedienung    Ersatzfernbedienung**

	0		0
	Menu		Menu
	Red/Zoom		Red
	Green/Repeat		Green
	Yellow/Root		Yellow
	Blue/Title		Blue
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	Ok/Selct		Ok
	P+		Ch +
	P-		Ch -
	Vol+		Vol +
	Vol-		Vol -
	FAV		Pre Ch
	Lang		Dual



