































Originalfernbedienung Ersatzfernbedienung

	Power		Power
	Mute		Mute / Dimmer
	DTV		Shift + 1
	Radio		TV/Radio /
	USB		Shift + 8
	DVD		Shift + 2
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	TV Guide		Guide / EPG / -/--
	0		0

Originalfernbedienung Ersatzfernbedienung

	Recall		Back / Return
	Vol +		Vol+
	P.Mode		Picture / Format
	CH +		CH+ / Page+
	Vol -		Vol-
	S.Mode		Sound / Title
	CH -		CH- / Page-
	FAV		Fav / Marker / PC
	Menu		Menu / Home
	Up		Up
	Exit		Exit / Cancel / Clear
	Left		Left
	OK		OK
	Right		Right
	Source		AV / Input / RDS
	Down		Down
	Info		Info / Angle



