







































































Originalfernbedienung Ersatzfernbedienung

	Power		Power
	Bonusview		Media
	Open / Close		Eject
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	Subtitle		Subt
	Audio		Dual
	l<<		l<<
	>>l		>>l

Originalfernbedienung Ersatzfernbedienung

	<<		<<
	>>		>>
	Stop		Stop
	Play		Play
	Pause		Pause
	Disc Menu		D. Menu
	Menu		Menu
	Popup / Title	 + 	Shift + Menu
	Popup / Title		List
	Tools		Options
	Info		Info
	Up		Up
	Left		Left
	Enter		Ok
	Right		Right
	Down		Down
	Return		Back



