















































Originalfernbedienung	Ersatzfernbedienung	Originalfernbedienung	Ersatzfernbedienung
On/Off		Power	
Audio Off		Mute	
Slow Down		Ch -	
Stop		Stop	
Subt.		Subt	
Auto/Track		TV/R	
Slow Up		Ch +	
Pause		Pause	
Rep/A-B	 + 	Shift + Text	
Title		List	
Repeat/1/All		Text	
Zoom	 + 	Shift + Eject	
DVD/TV		AV	
Menu		Menu	
Menu Up		Up	
Display		Info	
Menu Left		Left	
OK Enter		Ok	
Menu Right		Right	
Return		Back	
Menu Down		Down	
Progr.		Sleep	
Volume+		Vol +	
Next		>>	
Volume-		Vol -	
Top Menu	 + 	Shift + Menu	
1		1	
Prev.		<<	
2		2	
3		3	
4		4	
5		5	
6		6	
7		7	



Originalfernbedienung	Ersatzfernbedienung	Originalfernbedienung	Ersatzfernbedienung
8			
9			
+10			
0			
C/CH			
Record			
Open/Close			
Rewind			
F.Forward			
Setup			
Play			
Mode			
Video			
Syst.Preset			
Audio			
Clear/00:00			
Angle	