



Originalfernbedienung Ersatzfernbedienung

| | | | |
|---|------------|---|--------------------|
|  | Power |  | Power |
|  | 1 |  | 1 |
|  | 2 |  | 2 |
|  | 3 |  | 3 |
|  | 4 |  | 4 |
|  | 5 |  | 5 |
|  | 6 |  | 6 |
|  | 7 |  | 7 |
|  | 8 |  | 8 |
|  | 9 |  | 9 |
|  | 0 |  | 0 |
|  | P+ |  | CH+ / Page+ |
|  | P- |  | CH- / Page- |
|  | Vol+ |  | Vol+ |
|  | Vol- |  | Vol- |
|  | Open/Close |  | Eject / Surround |
|  | Guide |  | Guide / EPG / -/-- |

Originalfernbedienung Ersatzfernbedienung

| | | | |
|---|--------------|---|-----------------------|
|  | Mute |  | Mute / Dimmer |
|  | I<< |  | I<< / Preset- |
|  | >>I |  | >>I / Preset+ |
|  | << |  | << / Tune- |
|  | >> |  | >> / Tune+ |
|  | Stop |  | Stop / Hold |
|  | Pause |  | Pause / Step / Freeze |
|  | Play |  | Play / Slow |
|  | Info |  | Info / Angle |
|  | Exit |  | Exit / Cancel / Clear |
|  | Media Center |  | Display / Media |
|  | Up |  | Up |
|  | Home Menu |  | Menu / Home |
|  | Pop-Up Menu |  | D.Menu / Top |
|  | Down |  | Down |
|  | Left |  | Left |
|  | Right |  | Right |



