






































































Originalfernbedienung Ersatzfernbedienung

	Power		Power
	USB		Smart
	Radio		TV/R
	Coax		3D
	AUX		AV
	MP3 Link		Media
	Audio		Dual
	Setup		Menu
	Back		Back
	Info		Info
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	OK		Ok
	>>		>>
	<<		<<

Originalfernbedienung Ersatzfernbedienung

	l<		l<<
	Play/Pause		Play
	>l		>>l
	Stop		Stop
	Vol+		Vol +
	Vol-		Vol -
	Mute		Mute
	Surround		Options
	Treble		Ch +
	Bass		Ch -
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7





Originalfernbedienung	Ersatzfernbedienung	Originalfernbedienung	Ersatzfernbedienung
8	8		
9	9		
0	0		
SUBTITLE	Subtitle		
AUDIO SYNC	Audio Sync		
REPEAT PROGRAM	Repeat/Program		
REPEAT A-B	Repeat A-B		
ZOOM	Zoom		
SOUND MODE	Sound Mode		

