



Originalfernbedienung Ersatzfernbedienung

	Standby		Power
	Open / Close		Eject
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	Search	 + 	Shift + TV/R
	Clear		Exit
	Program+		Ch +
	Program-		Ch -
	Return		Back

Originalfernbedienung Ersatzfernbedienung

	HDD/DVD		Media
	Up		Up
	Left		Left
	Select		Ok
	Right		Right
	Down		Down
	Setup		Options
	TV/DVD		Smart
	Video Source		AV
	Function		D. Menu
	Playlist+		Vol +
	Playlist-		Vol -
	Watch TV		TV/R
	Play/Pause		Play
	Play/Pause		Pause
	Stop		Stop
	Record/DUB		Rec



