















**Originalfernbedienung Ersatzfernbedienung**

	Power		Power
	Gravar		Rec
	Lista		List
	Silêncio		Mute
	Guia TV		Guide
	Áudio		Dual
	Info		Info
	Teletexto		Text
	Legendas		Subt
	Menu		Menu
	Sair		Exit
	Up / P+		Up
	Up / P+		Ch +
	Down / P-		Down
	Down / P-		Ch -
	Right / Vol+		Vol +
	Right / Vol+		Right

**Originalfernbedienung Ersatzfernbedienung**

	Left / Vol-		Left
	Left / Vol-		Vol -
	OK		Ok
	Multimédia		Media
	TV / Rádio		TV/R
	Voltar		Back
	Ir		Pre Ch
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0



