


























































Originalfernbedienung Ersatzfernbedienung

	Power		Power
	Mute		Mute
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
		 + 	Shift + Guide
	Recall		Back
	Menu		Menu
	Source		AV
	Exit		Exit

Originalfernbedienung Ersatzfernbedienung

	Tv Display		Info
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	Enter		Ok
	Vol+		Vol +
	Vol-		Vol -
	S.M.		Smart
	P.M.		Media
	CH+		Ch +
	CH-		Ch -
	EPG Page Up	 + 	Shift + Up
	EPG Page Down	 + 	Shift + Down
	Sleep		Sleep
	P.G.		Format
	Aspect		3D



