




Originalfernbedienung Ersatzfernbedienung

	On / Off		Power
	Mute All		Shift + Mute
	Mute		Mute
	Stored		List
	CD - DVD		Shift + 1
	FM - AM		Shift + 2
	TV		Shift + 3
	CBL - SAT		Shift + 4
	AUX		Shift + 5
	VCR		Shift + 6
	Up / Tune +		Up
	Library		Text
	Down / Tune -		Down
	Left		Left
	Right		Right
	Enter		Ok
	Settings		Options

Originalfernbedienung Ersatzfernbedienung

	System		Menu
	DVD Menu		D. Menu
	Guide		Guide
	Exit		Exit
	Volume +		Vol +
	Volume -		Vol -
	Track/Chap./CH +		Ch +
	Track/Chap./CH -		Ch -
	Stop		Stop
	Pause		Pause
	Play		Play
	I<< Seek		I<<
	>>I Seek		>>I
	Shuffle		Smart
	Repeat		Media
	1		1
	2		2









Originalfernbedienung Ersatzfernbedienung

	On / Off		Power
	Mute All		Shift + Mute
	Mute		Mute
	Stored		List
	CD - DVD		Shift + 1
	FM - AM		Shift + 2
	TV		Shift + 3
	CBL - SAT		Shift + 4
	AUX		Shift + 5
	VCR		Shift + 6
	Up / Tune +		Up
	Library		Text
	Down / Tune -		Down
	Left		Left
	Right		Right
	Enter		Ok
	Settings		Options

Originalfernbedienung Ersatzfernbedienung

	System		Menu
	DVD Menu		D. Menu
	Guide		Guide
	Exit		Exit
	Volume +		Vol +
	Volume -		Vol -
	Track/Chap./CH +		Ch +
	Track/Chap./CH -		Ch -
	Stop		Stop
	Pause		Pause
	Play		Play
	I<< Seek		I<<
	>>I Seek		>>I
	Shuffle		Smart
	Repeat		Media
	1		1
	2		2



