


Originalfernbedienung Ersatzfernbedienung

	I<< Skip		I<<
	Skip >>I		>>I
	Open		Eject
	<< Search		<<
	Search >>		>>
	Play		Play
	< Index		Left
	Index >		Right
	Pause		Pause
	Display		Info
	Repeat		Text
	Stop		Stop
	1		1
	2		2
	3		3
	4		4
	5		5



































Originalfernbedienung Ersatzfernbedienung

	6		6
	7		7
	8		8
	9		9
	0		0
	Mute		Mute
	Vol-		Vol -
	Vol+		Vol +
	Bal L		Ch -
	Bal R		Ch +

















Originalfernbedienung Ersatzfernbedienung

	Tune-		Ch -
	Tune+		Ch +
	Preset		Smart
	Scan		Media
	Tune		TV/R
	Band		Dual
	Signal		Back
	Store		Exit
	Mono		Subt
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8

Originalfernbedienung Ersatzfernbedienung

	9		9
	0		0
	Mute		Mute
	Vol-		Vol -
	Vol+		Vol +
	Bal L		Left
	Bal R		Right

