







Originalfernbedienung Ersatzfernbedienung

	Power		Power
	Mute		Mute / Dimmer
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	TV / Radio		TV/Radio /
	0		0
	Recall / Mouse		Back / Return
	P.Mode		Picture / Format
	S.Mode		Sound / Title
	Nicam / A2		Audio / Lang I/II

Originalfernbedienung Ersatzfernbedienung

	Sleep		Sleep / Timer
	Source		AV / Input / RDS
	CH +		CH+ / Page+
	Vol +		Vol+
	Info		Info / Angle
	CH -		CH- / Page-
	Vol -		Vol-
	Home		Shift + Menu /
	FAV		Fav / Marker / PC
	Settings		Setup / OPT /
	ASP		Smart / List
	Up		Up
	Left		Left
	OK		OK
	Right		Right
	Menu		Menu / Home
	Down		Down



