













































Originalfernbedienung Ersatzfernbedienung

| | | | |
|---|--------------|---|--------|
|  | Power |  | Power |
|  | Sleep |  | Sleep |
|  | [i+] |  | Info |
|  | Menu |  | Menu |
|  | DTV Menu |  | Smart |
|  | Mute |  | Mute |
|  | ▼/O)/II/I+II |  | Dual |
|  | DTV |  | Media |
|  | Recall |  | Pre Ch |
|  | Source |  | AV |
|  | 1 |  | 1 |
|  | 2 |  | 2 |
|  | 3 |  | 3 |
|  | 4 |  | 4 |
|  | 5 |  | 5 |
|  | 6 |  | 6 |
|  | 7 |  | 7 |

Originalfernbedienung Ersatzfernbedienung

| | | | |
|---|--------|---|---------------|
|  | 8 |  | 8 |
|  | 9 |  | 9 |
|  | 0 |  | 0 |
|  | Vol+ |  | Vol + |
|  | Vol- |  | Vol - |
|  | P+ |  | Ch + |
|  | P- |  | Ch - |
|  | Radio |  | TV/R |
|  | PC |  | Shift + Media |
|  | [> <] |  | Format |
|  | End |  | Exit |
|  | Return |  | Back |
|  | [<>] |  | D. Menu |
|  | OK |  | Ok |
|  | Up |  | Up |
|  | Down |  | Down |
|  | Left |  | Left |



