





































Originalfernbedienung Ersatzfernbedienung



































	Power		Power
	Timer		Sleep
	Timer		AV
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	<		Left
	>		Right
	Red		Red
	Green		Green

Originalfernbedienung Ersatzfernbedienung



	Yellow		Yellow
	Blue		Blue
	Menu		Menu
	Info		Info
	Up		Up
	Left		I<<
	OK		Ok
	Right		>>I
	Down		Down
	Guide		Guide
	PVR		Smart
	Plugin		3D
	Exit		Exit
	PIP		Format
	Vol+		Vol +
	Vol-		Vol -
	Audio		Dual




Originalfernbedienung Ersatzfernbedienung

	Mute		Mute
	CH+		Ch +
	CH-		Ch -
	REW		<<
	Play / Pause		Play
	Play / Pause		Pause
	FF		>>
	Rec		Rec
	File List		List
	Stop		Stop
	Radio / TV		TV/R
	FAV		Pre Ch
	Subt		Subt
	Text		Text
	www		Media
	Setup		Options
	LAN		Eject

Originalfernbedienung Ersatzfernbedienung

	Help		D. Menu

