







































































Originalfernbedienung		Ersatzfernbedienung		Originalfernbedienung		Ersatzfernbedienung	
	Power		Power		Source		SRC
	Display		VOD		PIP		WIDE
	Mute		MUTE		TV		TV/R
	Video		MEDIA		PC		Shift + TV/R
	Scart		Shift + MEDIA		Sound		Audio
	1		1		Sleep		Shift + Power
	2		2		Swap		BACK
	3		3		Zoom -		Shift + LEFT
	4		4		Zoom +		Shift + RIGHT
	5		5		Vol +		VOL +
	6		6		Vol -		VOL -
	7		7		CH +		CH +
	8		8		CH -		CH -
	9		9		Menu		MENU
	0		0		Exit		EXIT
	Subpage		-/-- / EPG		Up		UP
	Pre-Ch		P/C / FAV		Down		DOWN



