



















































































Original	Replacement
 Power	 Power
 OK	 OK
 Up	 UP
 Down	 DOWN
 Right	 RIGHT
 Left	 LEFT
 Return	 BACK
 Play	 Play
 Pause	 Pause
 Extra	 MEDIA
 Mute	 MUTE
 Vol+	 VOL +
 Vol-	 VOL -
 Guide	 -/-- / EPG
 CH+	 CH +
 CH-	 CH -
 Home	 VOD

Original	Replacement
 Source	 SRC
 TTX/MIX	 TEXT
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 PRE-CH	 P/C / FAV
 Exit	 EXIT
 Info	 INFO
 Menu	 MENU
 Red	 Red (A)





Original	Replacement	Original	Replacement
Green	 Green (B)		
Yellow	 Yellow (C)		
Blue	 Blue (D)		
	 TV/R		
Tools	 OPT+		
Stop	 Stop		
Rec	 Rec		
<</ <<	 Rewind		
>>/>>	 Fast Forward		
CH List	 WIDE		
AD/Subt.	 Subt.		
E-Manual	 Audio		

