




























Original	Replacement	Original	Replacement
 Power	 Power	 Time/Text	 Text
 1	 1	 Timer	 Shift + AV
 2	 2	 Tv/Video	 TV/R
 3	 3	 [...]	 Subt
 4	 4	 O)))	 Dual
 5	 5	 -/--/Clear	 Guide
 6	 6	 System Menu	 Menu
 7	 7	 Title List	 List
 8	 8	 Timer List	 Format
 9	 9	 Menu	 D. Menu
 0	 0	 Top Menu	 Shift + Menu
 PR+	 Ch +	 Eject	 Eject
 PR-	 Ch -	 Return	 Back
 Vol+	 Vol +	 Tools	 Options
 Vol-	 Vol -	 Enter	 Ok
 Input Select	 AV	 Up	 Up
 Display	 Info	 Down	 Down





Original	Replacement	Original	Replacement
	Right		Right
	Left		Left
	Play		Play
	Stop		Stop
	Pause		Pause
	>>/I>		>>
	<</<I		<<
	>>I		>>I
	I<<		I<<
	→		SHIFT + 
	←		SHIFT + 
	Visual Search		Blue
	Set		Pre Ch
	Sur		Sleep
	Rec		Rec
	Rec Pause		SHIFT + 
	Rec Stop		SHIFT + 
	Rec Mode		SHIFT + 
	Synchro Rec		3D
	Chapter Mark		Red
	Mark Erase		SHIFT + 
	Camera		Exit
	Progressive		Green
	[+]		Yellow
	Power Tv		SHIFT + 
	HDD		Smart
	DVD		Media
	1 Tv		SHIFT + 
	2 Tv		SHIFT + 
	3 Tv		SHIFT + 
	4 Tv		SHIFT + 
	5 Tv		SHIFT + 
	6 Tv		SHIFT + 
	7 Tv		SHIFT + 



