





















Original	Replacement
 Power	 Power
 Mute	 Mute
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 TV / R	 TV/R
 Home	 Smart
 FAV	 Pre Ch
 Back	 Back
 Audio	 Dual

Original	Replacement
 Info	 Info
 EPG	 Guide
 Up	 Up
 Left	 Left
 OK	 Ok
 Right	 Right
 Down	 Down
 Menu	 Menu
 Exit	 Exit
 Vol +	 Vol +
 Vol -	 Vol -
 P +	 Shift + Ch +
 List	 List
 P -	 Shift + Ch -
 CH +	 Ch +
 CH -	 Ch -
 OPT	 Options





Original		Replacement		Original		Replacement	
	Text		Text				
	SUB		Subt				
	Message		Format				
	Pause		Pause				
	<<		<<				
	>>		>>				
	Rec		Rec				
	Play		Play				
	I<<		I<<				
	>>I		>>I				
	Stop		Stop				
	Red		Red				
	Green		Green				
	Yellow		Yellow				
	Blue		Blue				

