



| Original | Replacement |
|--|--|
|  Power |  Power |
|  Mute |  Mute / Dimmer |
|  Nicam/A2 |  Shift + Audio / Lang I/II |
|  Aspect |  Shift + Picture / Format |
|  P.Mode |  Picture / Format |
|  S.Mode |  Sound / Title |
|  1 |  1 |
|  2 |  2 |
|  3 |  3 |
|  4 |  4 |
|  5 |  5 |
|  6 |  6 |
|  7 |  7 |
|  8 |  8 |
|  9 |  9 |
|  Shift + Guide / EPG / -/-- |  Shift + Guide / EPG / -/-- |
|  0 |  0 |

| Original | Replacement |
|--|---|
|  Recall |  Back / Return |
|  Display |  Display / Media |
|  Freeze |  Pause / Step / Freeze |
|  Rec/Auto |  Rec / Rec Mode |
|  Red |  Red / Netflix / Search |
|  Green |  Green / APP / Repeat |
|  Yellow |  Yellow / YouTube / Repeat |
|  Blue |  Blue / Prime Video / Random |
|  Sleep |  Sleep / Timer |
|  Up |  Up |
|  Source |  AV / Input / RDS |
|  Left |  Left |
|  Enter |  OK |
|  Right |  Right |
|  Down |  Down |
|  Menu |  Menu / Home |
|  Exit |  Exit / Cancel / Clear |



