





























































Original	Replacement	Original	Replacement
 Power	 Power	 J/S.Mode	 Shift + Dual
 [i+]	 Info	 P.Mode	 Shift + Format
 DTT/TV	 TV/R	 Vol+	 Vol +
 Rec/AV1	 Rec	 Vol-	 Vol -
 Stop/AV2	 Stop	 I/II	 Dual
 Play/AV3	 Play	 Mute	 Mute
 AV4	 AV	 P+	 Ch +
 Pause/AV5	 Pause	 P-	 Ch -
 <</HDMI1/2	 <<	 1	 1
 >>/RGB	 >>	 2	 2
 Menu	 Menu	 3	 3
 Back	 Back	 4	 4
 Up	 Up	 5	 5
 Down	 Down	 6	 6
 Right	 Right	 7	 7
 Left	 Left	 8	 8
 OK	 Ok	 9	 9































Original		Replacement		Original		Replacement	
	0		0				
	[> <]/2-4-12		3D				
	[≡]		Options				
	Red		Red				
	Green		Green				
	Yellow		Yellow				
	Blue		Blue				
	[≡ i]		List				
	[≡ X]		Smart				
	[...]/Slide Show		Subt				
	[≡ ?]/Rotate		Pre Ch				
	[≡]/Text		Text				
	Swivel		Sleep				
	[<>]		Format				
	Photo		Media				










































	Original	Replacement	Original	Replacement
	Power			
	OK			
	Up			
	Down			
	Right			
	Left			
	Menu			
	Play/AV3			
	Stop/AV2			
	Pause/AV5			
	<</HDMI 1/2			
	>>/RGB			
	P+			
	P-			





	Original	Replacement		Original	Replacement
	Power		Power		8
	OK		Ok		9
	Up		Up		0
	Down		Down		
	Right		Right		
	Left		Left		
	P+		Ch +		
	P-		Ch -		
	Vol+		Vol +		
	Vol-		Vol -		
	1		1		
	2		2		
	3		3		
	4		4		
	5		5		
	6		6		
	7		7		

