












































































Original		Replacement		Original		Replacement	
	Power		Power		P-		Ch -
	TV / DTV		Smart		AV		AV
	Guide		Guide		Mute		Mute
	Up		Up		Vol+		Vol +
	Left		Left		Vol-		Vol -
	OK		Ok		1		1
	Right		Right		2		2
	Down		Down		3		3
	Menu		Menu		4		4
	Back		Back		5		5
	Zoom		Eject		6		6
	O↔O		Shift + Dual		7		7
	Red		Red		8		8
	Green		Green		9		9
	Yellow		Yellow		0		0
	Blue		Blue		(i)		Info
	P+		Ch +		[≡]		Text





Original	Replacement	Original	Replacement
	[≡i] SHIFT + DISPLAY INFO Shift + Info		
	[↓] ECO 3D 3D		
	[?] APP MEDIA Media		
	[□] Stop		
	TV / Radio SEARCH TV/R TV/R		
	I / II SOUND DUAL Dual		
	[⊕] SHIFT + AD SUBT Shift + Subt		
	[...] AD SUBT Subt		

