







































Original	Replacement
 Open/Close	 Eject / Surround
 Sleep	 Sleep / Timer
 Clock	 Shift + Sleep / Timer
 Power	 Power
 Internet Radio	 Display / Media
 USB	 Shift + 8
 Music Servers	 Audio / Lang I/II
 Tuner	 Shift + 6
 Analog In	 AV / Input / RDS
 Optical In	 D.Menu / Top
 CD	 Shift + 3
 Bluetooth	 Shift + 9
 I<</CH-	 I<< / Preset-
 Play	 Play / Slow
 Pause	 Pause / Step / Freeze
 >>I/CH+	 >>I / Preset+
 Speaker A/B	 Yellow / YouTube / Repeat

Original	Replacement
 Stop	 Stop / Hold
 Volume A/B	 Red / Netflix / Search
 ADD Favorites	 CH+ / Page+
 DBB/Tone	 Subtitle / EQ
 Volume+	 Vol+
 Call Favorites	 CH- / Page-
 Mute	 Mute / Dimmer
 Volume-	 Vol-
 Queue	 Smart / List
 Up/Tune+	 Up
 Option/Program	 Setup / OPT /
 Left	 Left
 Enter	 OK
 Right	 Right
 Back	 Back / Return
 Down/Tune-	 Down
 Setup	 Menu / Home





	Original	Replacement	Original	Replacement
	1	 1		
	2	 2		
	3	 3		
	4	 4		
	5	 5		
	6	 6		
	7	 7		
	8	 8		
	9	 9		
	+10	 Guide / EPG / -/--		
	0	 0		
	Clear	 Exit / Cancel / Clear		
	Random	 Blue / Prime Video / Random		
	Repeat	 Green / APP / Repeat		
	Dimmer	 Shift + Mute / Dimmer		
	Info	 Info / Angle		

