





































| Original | Replacement | Original | Replacement |
|---|--------------|---|-----------------------|
|  | Power |  | Power |
|  | Mute |  | Mute / Dimmer |
|  | PPV |  | TV/Radio / |
|  | Opciones |  | Setup / OPT / |
|  | Video Club |  | Subtitle / EQ |
|  | Menu |  | Menu / Home |
|  | Guia |  | Guide / EPG / -/-- |
|  | Idiomas |  | Audio / Lang I/II |
|  | Herramientas |  | Smart / List |
|  | Tv/Salir |  | Exit / Cancel / Clear |
|  | ?/Ayuda |  | Fav / Marker / PC |
|  | Atras |  | Back / Return |
|  | B. |  | Display / Media |
|  | Info |  | Info / Angle |
|  | Vol+ |  | Vol+ |
|  | Up |  | Up |
|  | PRG+ |  | CH+ / Page+ |

| Original | Replacement | Original | Replacement |
|---|-------------|---|-----------------------------|
|  | Vol- |  | Vol- |
|  | << |  | << / Tune- |
|  | Left |  | Left |
|  | OK |  | OK |
|  | Play |  | Play / Slow |
|  | Pause |  | Pause / Step / Freeze |
|  | Right |  | Right |
|  | >> |  | >> / Tune+ |
|  | PRG- |  | CH- / Page- |
|  | Down |  | Down |
|  | Stop |  | Stop / Hold |
|  | Red |  | Red / Netflix / Search |
|  | Gray |  | Zoom / Size |
|  | Green |  | Green / APP / Repeat |
|  | Yellow |  | Yellow / YouTube / Repeat |
|  | Blue |  | Blue / Prime Video / Random |
|  | 1 |  | 1 |



