














































































Original	Replacement	Original	Replacement
 Power	 Power	 Time/Text	 Text
 1	 1	 Timer	 Shift + AV
 2	 2	 Tv/Video	 TV/R
 3	 3	 [...]	 Subt
 4	 4	 O)))	 Dual
 5	 5	 -/--/Clear	 Guide
 6	 6	 System Menu	 Menu
 7	 7	 Title List	 List
 8	 8	 Timer List	 Format
 9	 9	 Menu	 D. Menu
 0	 0	 Top Menu	 Shift + Menu
 PR+	 Ch +	 Eject	 Eject
 PR-	 Ch -	 Return	 Back
 Vol+	 Vol +	 Tools	 Options
 Vol-	 Vol -	 Enter	 Ok
 Input Select	 AV	 Up	 Up
 Display	 Info	 Down	 Down





Original	Replacement	Original	Replacement
	Right		Right
	Left		Left
	Play		Play
	Stop		Stop
	Pause		Pause
	>>/I>		>>
	<</<I		<<
	>>I		>>I
	I<<		I<<
	→	 + 	Shift + Right
	←	 + 	Shift + Left
	Visual Search		Blue
	Set		Pre Ch
	Sur		Sleep
	Rec		Rec
	Rec Pause	 + 	Shift + Pause
	Rec Stop	 + 	Shift + Stop
	Rec Mode	 + 	Shift + Rec
	Synchro Rec		3D
	Chapter Mark		Red
	Mark Erase	 + 	Shift + Eject
	Camera		Exit
	Progressive		Green
	[+]		Yellow
	Power Tv	 + 	Shift + Power
	HDD		Smart
	DVD		Media
	1 Tv	 + 	Shift + 1
	2 Tv	 + 	Shift + 2
	3 Tv	 + 	Shift + 3
	4 Tv	 + 	Shift + 4
	5 Tv	 + 	Shift + 5
	6 Tv	 + 	Shift + 6
	7 Tv	 + 	Shift + 7





Original	Replacement	Original	Replacement
 8 Tv	 +  Shift + 8		
 9 Tv	 +  Shift + 9		
 0 Tv	 +  Shift + 0		
 -/--/Clear Tv	 +  Shift + Guide		
 Prog + Tv	 +  Shift + Ch +		
 Prog - Tv	 +  Shift + Ch -		
 Tv/Video Tv	 +  Shift + TV/R		

