Originalfernbedienung	Ersatzfernbedienung
Eject	Eject / Surround
Power	Power
Disc	Shift + 2
Radio	Shift + 6
iPod	Shift + 3
AUX	Shift + 7
Settings	Setup / OPT /
Repeat	Shift + Green / APP /
A-B	Shift + Yellow / YouTube /
Display	Display / Media
1	1
2	2
3	3
4	4
5	5
6	6
7	7

Originalfernbedienung	Ersatzfernbedienung
8	8
9	9
Clear	Shift + Exit / Cancel / Clear
0	0
Find	Shift + Red / Netflix /
Home	Menu / Home
Surround	Shift + Eject / Surround
Options	Shift + Setup / OPT / Tools
Up	Up
Left	Left
OK	OK
Right	Right
Down	Down
Exit	Exit / Cancel / Clear
Top Menu	D.Menu / Top
Pop-Up	Guide / EPG / -/--
I<<	I<< / Preset-

Originalfernbedienung		Ersatzfernbedienung		Originalfernbedienung	Ersatzfernbedienung
	>>I	PRESET+	>>I / Preset+		
	<<	TUNE-	<< / Tune-		
	>>	TUNE+	>> / Tune+		
	Stop	HOLD	Stop / Hold		
	Play	SLOW	Play / Slow		
	Pause	STEP-FREEZE	Pause / Step / Freeze		
VOLUME +	Volume+	VOL +	Vol +		
MUTE	Mute	DIMMER MUTE	Mute / Dimmer		
CHANNEL +	Channel +	CH PAGE +	CH+ / Page+		
VOLUME -	Volume-	VOL -	Vol -		
CHANNEL -	Channel -	CH PAGE -	CH- / Page-		
PROGRAM	Red/ Program	NETFLIX SEARCH	Red / Netflix / Search		
BOOKMARK	Green/ Bookmar	APP REPEAT	Green / APP / Repeat		
THUMBNAIL	Yellow/ Thumbnail	YouTube REPEAT A-B	Yellow / YouTube / Repeat		
ZOOM	Blue/ Zoom	Prime Video RANDOM	Blue / Prime Video / Random		

Originalfernbedienung		Ersatzfernbedienung	
EJECT	Eject	SURROUND	Eject / Surround
POWER	Power		Power
REPEAT	Repeat	SHIFT + APP REPEAT	Shift + Green / APP /
A-B	A-B	SHIFT + YouTube REPEAT A-B	Shift + Yellow / YouTube /
DISPLAY	Display	MEDIA DISPLAY	Display / Media
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
CLEAR	Clear	SHIFT + CLEAR EXIT CANCEL	Shift + Exit / Cancel / Clear
0	0	HDMI - SAT 0	0
FIND	Find	SHIFT + NETFLIX SEARCH	Shift + Red / Netflix / Search

Originalfernbedienung		Ersatzfernbedienung	
	Up		Up
	Left		Left
OK	OK	OK	OK
	Right		Right
	Down		Down
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
TOP MENU	Top Menu	TOP MENU D.MENU	D.Menu / Top
POP-UP	Pop-Up	-/-- GUIDE EPG	Guide / EPG / -/--
⏮	I<<	PRESET- ⏮	I<< / Preset-
⏭	>>I	PRESET+ ⏭	>>I / Preset+
⏪	<<	TUNE- ⏪	<< / Tune-
⏩	>>	TUNE+ ⏩	>> / Tune+
■	Stop	HOLD ■	Stop / Hold
▶	Play	SLOW ▶	Play / Slow
⏸	Pause	STEP - FREEZE ⏸	Pause / Step / Freeze
VOLUME +	Volume+	VOL +	Vol +
MUTE	Mute	DIMMER MUTE	Mute / Dimmer

Originalfernbedienung	Ersatzfernbedienung	Originalfernbedienung	Ersatzfernbedienung
Channel +	CH+ / Page+		
Volume-	Vol -		
Channel -	CH- / Page-		
Red/ Program	Red / Netflix / Search		
Green/ Bookmar	Green / APP / Repeat		
Yellow/ Thumbnail	Yellow / YouTube / Repeat		
Blue/ Zoom	Blue / Prime Video / Random		