Original	Replacement	Original	Replacement
Mute	Mute / Dimmer	Info	Info / Angle
Power	Power	Left	Left
PP	Back / Return	Up	Up
I-II	Audio / Lang I/II	P+	CH+ / Page+
1	1	Right	Right
2	2	Down	Down
3	3	P-	CH- / Page-
4	4	Vol -	Vol -
5	5	Vol +	Vol +
6	6	Red/ Sound	Red / Netflix / Search
7	7	Red/ Sound	Sound / Title
8	8	Green/ Picture	Green / APP / Repeat
9	9	Green/ Picture	Picture / Format
0	0	Yellow/ Feature	Yellow / YouTube / Repeat
--	Guide / EPG / -/--	Blue/ Install	Blue / Prime Video / Random
P<P	Fav / Marker / PC	TV	TV/ Radio /
Menu	Menu / Home	AV	AV / Input / RDS

Original	Replacement	Original	Replacement
[≡]	GOTO TEXT Text / Goto		
[/≡]	SHIFT + GOTO TEXT Shift + Text /		
[≡o]	TIMER SLEEP Sleep / Timer		
[≡+]	HOLD ■ Stop / Hold		
[≡x]	OPT-TOOLS SETUP Setup / OPT /		
[≡♦]	SIZE ZOOM Zoom / Size		
[≡?]	LIST SMART Smart / List		
[≡i]	MEDIA DISPLAY Display / Media		