Original		Replacement	
	Power		Power
1	1	1	1
2abc	2	2	2
3def	3	3	3
4ghi	4	4	4
5jkl	5	5	5
6mno	6	6	6
7pqrs	7	7	7
8tuv	8	8	8
9wxyz	9	9	9
0	0	0	0
DEL	Del	FAV PRE-CH	Pre Ch
INPUT SELECT	Input Select	TIMER AV	AV
DRIVE SELECT	Select Drive	E-MANUAL D.MENU	D. Menu
VIERA CAST	Cast Vieta	APP MEDIA	Media
FUNCTION MENU	Function Menu	TOP MENU MENU	Menu
DIRECT NAVIGATOR	Direct Navigator	DISC NAV LIST	List

Original		Replacement	
GUIDE	Guide	-/-- GUIDE	Guide
RETURN	Return	RETURN BACK	Back
OPTION	Option	SETTINGS OPT	Options
EXIT	Exit	CLEAR EXIT	Exit
STATUS i	i / Status	DISPLAY INFO	Info
PAUSE	Pause / Pause Live Tv		Pause
STOP	Stop		Stop
PLAY/x1.3	Play/x1.3	PLAY MODE	Play
I<< Skip			I<<
Skip >>I			>>I
<< Slow/Search			<<
Slow/Search >>			>>
PROG/CHECK	Prog/Check	PROG SLEEP	Sleep
OK	OK	OK	Ok
	Up		Up
	Down		Down
	Right		Right

Original		Replacement	
	Left		Left
	Red	A	Red
	Green	B	Green
	Yellow	C	Yellow
	Blue	D	Blue
REC	Rec	REC MODE	Rec
DIRECT TV REC	Direct Tv Rec	SEARCH TV/R	TV/R
REC MODE	Rec Mode	SHIFT + REC MODE	Shift + Rec
EXT LINK	Ext Link	HOME SMART	Smart
AUDIO	Audio	SOUND DUAL	Dual
STTL	[≡♦] / STTL	AD SUBT	Subt
TEXT	[≡] / Text	REPEAT TEXT	Text
DISPLAY	Display	SHIFT + DISPLAY INFO	Shift + Info
CHAPTER	Chapter	PICTURE FORMAT	Format
TIME SLIP	Time Slip	ECO 3D	3D
PAGE CH	CH/Page+	+ CH	Ch +
CH	CH/Page-	CH −	Ch -

Original		Replacement	
+ VOL	Vol + Tv	+ VOL	Vol +
− VOL	Vol - Tv	− VOL	Vol -
INPUT AV	AV / Input Tv	SHIFT + TIMER AV	Shift + AV
CH	CH + Tv	SHIFT + + CH	Shift + Ch +
CH	CH - Tv	SHIFT + CH −	Shift + Ch -
TV	Power Tv	SHIFT +	Shift + Power
AL SKIP +60s	Manual Skip +60s	SHIFT + FAV PRE-CH	Shift + Pre Ch
MANU -10s	Manual Skip -10s	SHIFT + -/-- GUIDE	Shift + Guide