Original		Replacement	
	Power		Power
	Mute	MUTE	Mute
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
	Recall	FAV PRE-CH	Pre Ch
	Input	TIMER AV	AV
DVD MENU MENU	Menu	TOP MENU MENU	Menu
	[<>]	PICTURE FORMAT	Format
	⊣[/] ←	AD SUBT	Subt

Original		Replacement	
EXIT	Exit	CLEAR EXIT	Exit
P▲	Up		Up
P▼	Down		Down
	Right		Right
	Left		Left
OK	OK	OK	Ok
P▲	P+	+ CH	Ch +
P▼	P-	CH −	Ch -
	Vol +	+ VOL	Vol +
	Vol -	VOL −	Vol -
	Red	A	Red
	Green	B	Green
	Yellow	C	Yellow
	Blue	D	Blue
♪	♪	SHIFT + SOUND DUAL	Shift + Dual
PC INPUT	PC Input	HOME SMART	Smart
	[i+]	DISPLAY INFO	Info

Original		Replacement		Original	Replacement
	O) I / I I	SOUND DUAL	Dual		
	[▼]	SEARCH TV/R	TV/ R		
	[≡] / [/ ≡] / [ ]	REPEAT TEXT	Text		
	[≡i]	DISC NAV LIST	Li st		
	[≡O]	RETURN BACK	Back		
	[≡?]	-/-- GUIDE	Gui de		
	[≡+]	APP MEDIA	Medi a		
	[≡♦]	ECO 3D	3D		
	[O] / [≡x]	ZOOM ⏏	Ej ect		

Original		Replacement	
	Power		Power
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
DVD MENU	Menu DVD	TOP MENU	Menu
EXIT	Exit	CLEAR EXIT	Exit
P▲	Up		Up
P▼	Down		Down
	Right		Right
	Left		Left

Original		Replacement	
OK	OK	OK	Ok
P▲	P+	+ CH	Ch +
P▼	P-	CH −	Ch -
	Vol +	+ VOL	Vol +
	Vol -	VOL −	Vol -
II/II▶	Pause/Step	II	Pause
▶	Play	PLAY MODE ▶	Play
◀◀	<<	<<	<<
▶▶	>>	>>	>>
⏏	Open/Close	ZOOM ⏏	Eject
■	Stop	■	Stop
I◀◀	I <<	I<<	I <<
▶▶I	>>I	>>I	>>I

Original		Replacement	
	Power		Power
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
	Input	TIMER AV	AV
P▲	Up		Up
P▼	Down		Down
P▲	P+	+ CH	Ch +
P▼	P-	CH −	Ch -
	Pause/Step		Pause

Original		Replacement	
	Play	PLAY MODE	Play
	<<		<<
	>>		>>
	Eject	ZOOM	Eject
	Stop		Stop
	I<<		I<<
	>>I		>>I