Original		Replacement	
	Power		Power
	Mute	MUTE	Mute
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
	i	DISPLAY INFO	Info
AV	AV	TIMER AV	AV
	Red	A	Red
	Green	B	Green
	Yellow	C	Yellow

Original		Replacement	
	Blue	D	Blue
TV/DTV	Tv/DTV	HOME SMART	Smart
MENU	Menu	TOP MENU MENU	Menu
	Up		Up
	Right		Right
	Down		Down
	Left		Left
OK	OK	OK	Ok
	[≡] / Text	REPEAT TEXT	Text
BACK	Back	RETURN BACK	Back
P	P+	CH +	Ch +
P	P-	CH −	Ch -
	Vol +	VOL +	Vol +
	Vol -	VOL −	Vol -
	^ / Hold	SHIFT +	Shift + Up
F.T/L	<< / F.T/L	<<	<<
SUB TITLE	Play / [?] / Title	AD SUBT	Subt

Original		Replacement		Original	Replacement
SUB TITLE	Play / [?] / Title	PLAY MODE	Play		
GUIDE	>> / Guide / Siz	-/-- GUIDE	Guide		
GUIDE	>> / Guide / Siz	>>	>>		
	v	SHIFT +	Shift + Down		
TOP MENU	Rec / Top Menu	REC MODE	Rec		
	Stop / [X]		Stop		
	Pause / [=i]		Pause		
ZOOM	Zoom	ZOOM	Eject		
3D	3D	ECO 3D	3D		
	PIP Size	SHIFT + APP MEDIA	Shift + Media		
	Multiview	APP MEDIA	Media		

Original		Replacement		Original	Replacement
	Power		Power		
	Menu		Menu		
	Back		Back		
	OK		Ok		
	Up		Up		
	Down		Down		
	Right		Right		
	Left		Left		
	<<		<<		
	Play		Play		
	>>		>>		
	Stop		Stop		
	Pause		Pause		
	Rec/Top Menu		Rec		
	↑		Ch +		
	↓		Ch -		

Original		Replacement		Original	Replacement
	Power		Power		
	<<		<<		
	Play		Play		
	>>		>>		
	Rec		Rec		
	Pause		Pause		
	Stop		Stop		
	Up		Up		
	Down		Down		