Original		Replacement	
STANDBY	Standby		Power
INFO	Info		Info
SUBTITLE	Subtitle		Subt
MUTE	Mute		Mute
⏮	I<<		I<<
⏭	>>I		>>I
▶	Play		Play
⏸	Pause		Pause
◀◀	<<		<<
▶▶	>>		>>
MENU	Menu		Menu
EXIT	Exit		Exit
REC	Rec		Rec
■	Stop		Stop
CH+	CH+		Ch +
CH-	CH-		Ch -
CH+	Up		Up

Original		Replacement	
CH-	Down		Down
VOL+	Right		Right
VOL-	Left		Left
OK	OK		Ok
VOL+	Vol +		Vol +
VOL-	Vol -		Vol -
1	1		1
2	2		2
3	3		3
4	4		4
5	5		5
6	6		6
7	7		7
8	8		8
9	9		9
0	0		0
EPG	EPG		Guide

Original		Replacement		Original		Replacement	
BACK	Back		Back				
MEDIA	Medi a	SC NA	Medi a				
USB	USB		Smart				
TV/RADIO	Tv/ Radi o		TV/ R				
AUDIO	Audi o		Dual				
TTX	TTX	T	Text				
TIMER	Ti mer		AV				
FAV	FAV		Pre Ch				
RES	Res		3D				
	Red		Red				
	Gr een		Gr een				
	Yel l ow		Yel l ow				
	Bl ue		Bl ue				

Original		Replacement	
STANDBY	Standby		Power
INFO	Info		Info
SUBTITLE	Subtitle		Subt
MUTE	Mute		Mute
⏮	I<<		I<<
⏭	>>I		>>I
◀◀	<<		<<
▶▶	>>		>>
▶	Play		Play
⏸	Pause		Pause
REC	Record		Rec
■	Stop		Stop
MENU	Menu		Menu
EXIT	Exit		Exit
CH+	CH+		Ch +
CH-	CH-		Ch -
CH+	Up		Up

Original		Replacement	
CH-	Down		Down
VOL+	Right		Right
VOL-	Left		Left
OK	OK		Ok
VOL+	Vol +		Vol +
VOL-	Vol -		Vol -
EPG	EPG		Smart
BACK	Back		Back
1	1		1
2	2		2
3	3		3
4	4		4
5	5		5
6	6		6
7	7		7
8	8		8
9	9		9

Original		Replacement	
0	0		0
MEDIA	Media		Media
USB	USB		Options
TV/RADIO	Tv/Radio		TV/R
AUDIO	Audio		Dual
TTX	TTX		Text
FAV	FAV		Pre Ch
TIMER	Timer		AV
RES	Res		Guide
	Red		Red
	Green		Green
	Yellow		Yellow
	Blue		Blue

Original	Replacement