Original	Replacement	Original	Replacement
Power	Power	Exit / Back	Exit
Mute	Mute	Up	Up
1	1	Left	Left
2	2	OK	Ok
3	3	Right	Right
4	4	Down	Down
5	5	P+	Ch +
6	6	P-	Ch -
7	7	Vol +	Vol +
8	8	Vol -	Vol -
9	9	[◄ ►]	Format
0	0	→| ◪ ←|	TV/R
Recall	Pre Ch	[i+] / [≡i]	Info
Source	AV	Text / [≡][/≡][	Text
Menu/ DVD	Menu	▮▮/ ▮▮► / [▾]	Pause
Guide	Guide	► / I/II	Play
[■][▮▮]	3D	► / I/II	Dual

Original		Replacement		Original	Replacement
	◀◀ / [≡◀]		<<		
	◀◀ / [≡◀]	SETTINGS OPT	Options		
SUBTITLE	▶▶ / Subtitle	AD SUBT	Subt		
SUBTITLE	▶▶ / Subtitle		>>		
	▲	HOME SMART	Smart		
	■ / [≡□]		Stop		
	▮◀◀ / [≡↕]	ZOOM	Eject		
	▮◀◀ / [≡↕]		I <<		
	▶▶▮ / [◷][≡X]		>>I		
	▶▶▮ / [◷][≡X]	RETURN BACK	Back		
	Red	A	Red		
	Green	B	Green		
	Yellow	C	Yellow		
	Blue	D	Blue		

Original	Replacement	Original	Replacement
Power	Power	Right	Right
Mute	Mute	Down	Down
1	1	Vol +	Vol +
2	2	Vol -	Vol -
3	3	▮▮/ ▮▮▶ / [▾]	Pause
4	4	▶ / I/II	Play
5	5	▶ / I/II	Dual
6	6	◀◀ / [≡◀]	<<
7	7	◀◀ / [≡◀]	TV/R
8	8	▶▶ / Subtitle	>>
9	9	▶▶ / Subtitle	Subt
0	0	▲	Smart
_Menu/DVD	Menu	■ / [≡⏏]	Stop
_ Exit/Back	Exit	▮◀◀ / [≡↕]	Eject
– Up	Up	▮◀◀ / [≡↕]	I <<
Left	Left	▶▶▮ / [◷][≡X]	>>I
OK	Ok	▶▶▮ / [◷][≡X]	Back

Original		Replacement
	Power	Power
	Mute	Mute
1	1	1
2	2	2
3	3	3
4	4	4
5	5	5
6	6	6
7	7	7
8	8	8
9	9	9
0	0	0
	Source	AV
P	P+	Ch +
P	P-	Ch -
	Vol -	Vol -
	Vol +	Vol +

Original		Replacement
	▮▮/▮▮▶ / [▾]	Pause
	▶ / I/II	Play
	▶ / I/II	Dual
	◀◀ / [≡●]	<<
	◀◀ / [≡●]	TV/R
	▶▶ / Subtitle	>>
	▶▶ / Subtitle	Subt
	▲	Smart
	■ / [≡□]	Stop
	▮◀◀ / [≡↕]	Eject
	▮◀◀ / [≡↕]	I <<
	▶▶▮ / [◷][≡X]	Back
	▶▶▮ / [◷][≡X]	>>I