| Original | Replacement | Original | Replacement |
|---|---|---|---|
| Power | Power | Stop | Stop |
| Open / Close | Eject | Vol - | Vol - |
| CD | Green | Vol + | Vol + |
| TUNER | Red | 1 | 1 |
| USB / MP3 LINK | Yellow | 2 | 2 |
| TAPE | Blue | 3 | 3 |
| Up | Up | 4 | 4 |
| Left / I<< | Left | 5 | 5 |
| Left / I<< | I<< | 6 | 6 |
| Play/Pause | Pause | 7 | 7 |
| Play/Pause | Play | 8 | 8 |
| Play/Pause | Ok | 9 | 9 |
| Right / >>I | Right | 0 | 0 |
| Right / >>I | >>I | Prog | Sleep |
| Down | Down | Sleep / Timer | AV |
| Display / RDS | Info | DSC | Smart |
| Mute | Mute | DBB | Media |

| Original | | Replacement | |
|---|---|---|---|
| | Power | | Power |
| | Open / Close | | Eject |
| | CD | | Green |
| | TUNER | | Red |
| | USB / MP3 LINK | | Yellow |
| | TAPE | | Blue |
| | Up | | Up |
| | Left / I<< | | I<< |
| | Left / I<< | | Left |
| | Play / Pause | | Play |
| | Play / Pause | | Pause |
| | Play / Pause | | Ok |
| | Right / >>I | | Right |
| | Right / >>I | | >>I |
| | Down | | Down |
| | Display / RDS | | Info |
| | Mute | | Mute |

| Original | | Replacement | |
|---|---|---|---|
| | Stop | | Stop |
| | Vol - | | Vol - |
| | Vol + | | Vol + |
| 1 | 1 | 1 | 1 |
| 2 | 2 | 2 | 2 |
| 3 | 3 | 3 | 3 |
| 4 | 4 | 4 | 4 |
| 5 | 5 | 5 | 5 |
| 6 | 6 | 6 | 6 |
| 7 | 7 | 7 | 7 |
| 8 | 8 | 8 | 8 |
| 9 | 9 | 9 | 9 |
| 0 | 0 | 0 | 0 |
| PROG | Prog | SLEEP | Sleep |
| REPEAT/ SHUFFLE | Repeat / Shuffle | TEXT | Text |
| SLEEP/ TIMER | Sleep / Timer | AV | AV |
| DSC | DSC | SMART | Smart |

| Original | Replacement | Original | Replacement |
|---|---|---|---|
| DBB | Medi a | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |

| Original | | Replacement | |
|---|---|---|---|
| | Power | | Power |
| | Open/Close | | Eject |
| | CD | | Green |
| | TUNER | | Red |
| | USB / MP3 LINK | | Yellow |
| | TAPE | | Blue |
| | Up | | Up |
| | Left | | Left |
| | I<< | | I<< |
| | Ok | | Ok |
| | Pause | | Pause |
| | Play | | Play |
| | >>I | | >>I |
| | Right | | Right |
| | Down | | Down |
| | RDS/Display | | Info |
| | Mute | | Mute |

| Original | | Replacement | |
|---|---|---|---|
| | Stop | | Stop |
| | Vol - | | Vol - |
| | Vol + | | Vol + |
| 1 | 1 | 1 | 1 |
| 2 | 2 | 2 | 2 |
| 3 | 3 | 3 | 3 |
| 4 | 4 | 4 | 4 |
| 5 | 5 | 5 | 5 |
| 6 | 6 | 6 | 6 |
| 7 | 7 | 7 | 7 |
| 8 | 8 | 8 | 8 |
| 9 | 9 | 9 | 9 |
| 0 | 0 | 0 | 0 |
| PROG | Prog | SETTINGS OPT | Options |
| REPEAT/ SHUFFLE | Repeat/Shuffle | REPEAT TEXT | Text |
| SLEEP/ TIMER | Sleep/Timer | PROG SLEEP | Sleep |
| DSC | DSC | HOME SMART | Smart |

| Original | Replacement | Original | Replacement |
|---|---|---|---|
| DBB | Media | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |

| Original | | Replacement | |
|---|---|---|---|
| | Power | | Power |
| CD | CD | A | Red |
| TUNER | TUNER | B | Green |
| MP3 LINK USB | USB / MP3 LINK | C | Yellow |
| TAPE | TAPE | D | Blue |
| | I< | | I<< |
| | << | | << |
| | Play/Pause | PLAY MODE | Play |
| | Play/Pause | | Pause |
| | >I | | >>I |
| | >> | | >> |
| | Mute | MUTE | Mute |
| | Stop | | Stop |
| VOL - | Vol - | VOL - | Vol - |
| VOL + | Vol + | + VOL | Vol + |
| REPEAT/ SHUFFLE | Repeat | REPEAT TEXT | Text |
| REPEAT/ SHUFFLE | Shuffle | SEARCH TV/R | TV/R |

| Original | | Replacement | |
|---|---|---|---|
| SLEEP/ TIMER | Sleep | PROG SLEEP | Sleep |
| DSC | DSC | APP MEDIA | Media |
| DBB | DBB | HOME SMART | Smart |