Original	Replacement	Original	Replacement
Power	Power	OK	OK
Mute	Mute / Dimmer	Right	Right
Play/Pause	Play / Slow	Exit	Exit / Cancel / Clear
Stop	Stop / Hold	Down	Down
Rec	Rec / Rec Mode	Vol +	Vol +
<<	<< / Tune-	PVR	Smart / List
>>	>> / Tune+	Bouquet Up	CH+ / Page+
<	I<< / Preset-	Vol -	Vol -
>	>>I / Preset+	Help	Display / Media
Audio	Audio / Lang I/II	Bouquet Down	CH- / Page-
Radio	TV/Radio /	1	1
Text	Text / Goto	2	2
TV	AV / Input / RDS	3	3
Menu	Menu / Home	4	4
Up	Up	5	5
Info	Info / Angle	6	6
Left	Left	7	7

Original		Replacement		Original		Replacement	
	8		8				
	9		9				
	0		0				
	Red		Red / Netflix / Search				
	Green		Green / APP / Repeat				
	Yellow		Yellow / YouTube / Repeat				
	Blue		Blue / Prime Video / Random				

Original	Replacement	Original	Replacement
Power	Power	7	7
Mute	Mute / Dimmer	8	8
Up	Up	9	9
Info	Info / Angle	0	0
<	Left		
>	Right		
Down	Down		
Vol +	Vol +		
Bouquet Up	CH+ / Page+		
Vol -	Vol -		
Bouquet Down	CH- / Page-		
1	1		
2	2		
3	3		
4	4		
5	5		
6	6		