Original		Replacement	
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
P	P	GUIDE EPG	Guide / EPG / -/--
0	0	0	0
C	C	EXIT	Exit / Cancel / Clear
C	C	FAV MARKER	Fav / Marker / PC
I< Track		PRESET-	I<< / Preset-
Track >I		PRESET+	>>I / Preset+
REVIEW	Review	INFO	Info / Angle
STOP	Stop	HOLD	Stop / Hold

Original		Replacement	
PAUSE	Pause	STEP-FREEZE	Pause / Step / Freeze
PLAY	Play	SLOW	Play / Slow
FAST	Fast	OK	OK
FTS	FTS	MENU	Menu / Home
SEARCH	<< Search	TUNE-	<< / Tune-
SEARCH	Search >>	TUNE+	>> / Tune+
INDEX-	Index-	CH PAGE -	CH- / Page-
INDEX+	Index+	CH PAGE +	CH+ / Page+
SHUFFLE	Shuffle	Prime Video / RANDOM	Blue / Prime Video / Random
	Scan	DISPLAY	Display / Media
VOLUME-	Volume-	VOL -	Vol -
VOLUME+	Volume+	VOL +	Vol +
REPEAT	Repeat	APP / REPEAT	Green / APP / Repeat
TIME	Time	SLEEP	Sleep / Timer
FADER	Fader	MUTE	Mute / Dimmer
	A>B	YouTube / REPEAT A-B	Yellow / YouTube / Repeat

https://remotes.at/en/Philips/10838280-replacement-remote-control-for-Philips-RB01-RB01-01.htm