Mandis shop

CT03

Original		Replacement	
	Power		Power
	Mute	DIMMER MUTE	Mute / Dimmer
CLOCK	Clock	HOLD	Stop / Hold
12Hrs	12 Hrs	SLOW	Play / Slow
24Hrs	24 Hrs	STEP-FREEZE	Pause / Step / Freeze
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX-HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
0	0	HDMI-SAT 0	0
EDIT	Edit	-/-- GUIDE EPG	Guide / EPG / -/--

Original		Replacement	
	Left Up	VOL +	Vol +
	Right Up	CH PAGE +	CH+ / Page+
	Up		Up
	Left		Left
OK	OK	OK	OK
	Right		Right
	Down		Down
	Left Down	VOL −	Vol -
	Right Down	CH PAGE −	CH- / Page-
Up/Dn	Up/Dn	LIST SMART	Smart / List
	☼)	MEDIA DISPLAY	Display / Media
±10S	±10s	PC FAV MARKER	Fav / Marker / PC
INT	INT	NETFLIX SEARCH	Red / Netflix / Search
FGB	FGB	APP REPEAT	Green / APP / Repeat
TBT	TBT	YouTube REPEAT A-B	Yellow / YouTube / Repeat
	Timer	TIMER SLEEP	Sleep / Timer
	Timer	Prime Video RANDOM	Blue / Prime Video / Random

https://remotes.at/en/Capital-Sports-10283-963-replacement-remote-control-for-Capital-Sports-10283-CT03.htm