| Original | | Replacement | |
|---|---|---|---|
| ON/STANDBY | On/Standby | | Power |
| DISPLAY | Display | MEDIA DISPLAY | Display / Media |
| DVD/BD | DVD / BD | SHIFT + DVD 2 | Shift + 2 |
| VCR/DVR | VCR / DVR | SHIFT + VIDEO 4 | Shift + 4 |
| CBL/SAT | CBL/SAT | SHIFT + HDMI - SAT 0 | Shift + 0 |
| GAME | Game | SHIFT + BLUETOOTH 9 | Shift + 9 |
| AUX | AUX | SHIFT + AUX - HDD 7 | Shift + 7 |
| TV/TAPE | TV / TAPE | SHIFT + TAPE 5 | Shift + 5 |
| TV/TAPE | TV / TAPE | SHIFT + TV 1 | Shift + 1 |
| TUNER | TUNER | SHIFT + TUNER 6 | Shift + 6 |
| PORT | PORT | SHIFT + USB 8 | Shift + 8 |
| CD | CD | SHIFT + CD - STB 3 | Shift + 3 |
| MUTING | Muting | DIMMER MUTE | Mute / Dimmer |
| CH DISC | CH/Disc/Album | CH PAGE + | CH+ / Page+ |
| VOL | Vol + | VOL + | Vol + |
| ALBUM | CH/Disc/Album- | CH PAGE - | CH- / Page- |
| VOL | Vol - | VOL - | Vol - |

| Original | | Replacement | |
|---|---|---|---|
| | Up | | Up |
| PLAYLIST /CATEGORY | Left | | Left |
| ENTER | Enter | OK | OK |
| PLAYLIST /CATEGORY | Right | | Right |
| SETUP | Setup | OPT-TOOLS SETUP | Setup / OPT / |
| | Down | | Down |
| RETURN | Return | RETURN BACK | Back / Return |
| AUDIO | Audio | LANG I/II AUDIO | Audio / Lang I/II |
| | I<< | PRESET- | I<< / Preset- |
| | >>I | PRESET+ | >>I / Preset+ |
| | << | TUNE- | << / Tune- |
| | Play | SLOW | Play / Slow |
| | >> | TUNE+ | >> / Tune+ |
| | Pause | STEP-FREEZE | Pause / Step / Freeze |
| | Stop | HOLD | Stop / Hold |
| MOVIE/TV SEARCH | Movie Tv | NETFLIX SEARCH | Red / Netflix / Search |
| MUSIC REPEAT | Music | APP REPEAT | Green / APP / Repeat |

| Original | Replacement | Original | Replacement |
|---|---|---|---|
| Game | Yellow / YouTube / Repeat | | |
| Stereo | Blue / Prime Video / Random | | |
| 1 | 1 | | |
| 2 | 2 | | |
| 3 | 3 | | |
| 4 | 4 | | |
| 5 | 5 | | |
| 6 | 6 | | |
| 7 | 7 | | |
| 8 | 8 | | |
| 9 | 9 | | |
| +10/--/---10/Dimmer/D.Tun | Guide / EPG / -/-- | | |
| 0/11 | 0 | | |
| CLR/Sleep/12 | Fav / Marker / PC | | |
| CLR/Sleep/12 | Sleep / Timer | | |
| CLR/Sleep/12 | Exit / Cancel / Clear | | |

| Original | | Replacement | |
|---|---|---|---|
| | Power BD/DVD | | Power |
| | DVD/BD | | Smart / List |
| | CBL/SAT | | Display / Media |
| | Vol + Receiver | | Vol + |
| | Vol - Receiver | | Vol - |
| | Top Menu | | D.Menu / Top |
| | Up BD/DVD | | Up |
| | Menu BD/DVD | | Menu / Home |
| | Left BD/DVD | | Left |
| | Enter BD/DVD | | OK |
| | Right BD/DVD | | Right |
| | Setup BD/DVD | | Setup / OPT / |
| | Down BD/DVD | | Down |
| | Return BD/DVD | | Back / Return |
| | Audio BD/DVD | | Audio / Lang I/II |
| | I<< BD/DVD | | I<< / Preset- |
| | >>I BD/DVD | | >>I / Preset+ |

| Original | | Replacement | |
|---|---|---|---|
| | << BD/DVD | | << / Tune- |
| | Play BD/DVD | | Play / Slow |
| | >> BD/DVD | | >> / Tune+ |
| | Pause BD/DVD | | Pause / Step / Freeze |
| | Stop BD/DVD | | Stop / Hold |
| | Search BD/DVD | | Red / Netflix / Search |
| | Repeat BD/DVD | | Green / APP / Repeat |
| | Random | | Blue / Prime Video / Random |
| | Play Mode | | Yellow / YouTube / Repeat |
| | 1 BD/DVD | | 1 |
| | 2 BD/DVD | | 2 |
| | 3 BD/DVD | | 3 |
| | 4 BD/DVD | | 4 |
| | 5 BD/DVD | | 5 |
| | 6 BD/DVD | | 6 |
| | 7 BD/DVD | | 7 |
| | 8 BD/DVD | | 8 |

| Original | | Replacement | |
|---|---|---|---|
| 9 | 9 BD/DVD | BLUETOOTH 9 | 9 |
| +10 DIMMER | +10/--/--10 | -/-- GUIDE EPG | Guide / EPG / -/-- |
| 0 | 0/11 BD/DVD | HDMI - SAT 0 | 0 |
| CLR SLEEP | CLR/12 BD/DVD | PC FAV MARKER | Fav / Marker / PC |
| CLR SLEEP | CLR/12 BD/DVD | CLEAR EXIT CANCEL | Exit / Cancel / Clear |
| ON/STANDBY | Power CBL/SAT | SHIFT + | Shift + Power |
| CH DISC | CH Disc/Album+ CBL/SAT | SHIFT + CH PAGE + | Shift + CH+ / |
| ALBUM | CH Disc/Album- CBL/SAT | SHIFT + CH PAGE - | Shift + CH- / |
| GUIDE/TOP MENU | Guide CBL/SAT | SHIFT + -/-- GUIDE EPG | Shift + Guide / EPG / -/-- |
| | Up CBL/SAT | SHIFT + | Shift + Up |
| PREV CH/MENU VIDEO | Menu/Prev CH CBL/SAT | SHIFT + HOME MENU | Shift + Menu / |
| PLAYLIST /CATEGORY | Left CBL/SAT | SHIFT + | Shift + Left |
| ENTER | Enter CBL/SAT | SHIFT + OK | Shift + OK |
| PLAYLIST /CATEGORY | Right CBL/SAT | SHIFT + | Shift + Right |
| SETUP | Setup CBL/SAT | SHIFT + OPT-TOOLS SETUP | Shift + Setup / OPT / Tools |
| | Down CBL/SAT | SHIFT + | Shift + Down |
| RETURN | Return CBL/SAT | SHIFT + RETURN BACK | Shift + Back / Return |

| Original | | Replacement | |
|---|---|---|---|
| ◄◄ | << CBL/SAT | SHIFT + TUNE- ◄◄ | Shift + << / |
| ► | Play CBL/SAT | SHIFT + SLOW ► | Shift + Play / |
| ►► | >> CBL/SAT | SHIFT + TUNE+ ►► | Shift + >> / |
| ❚❚ | Pause CBL/SAT | SHIFT + STEP-FREEZE ❚❚ | Shift + Pause / Step / |
| ■ | Stop CBL/SAT | SHIFT + HOLD ■ | Shift + Stop / |
| MOVIE/TV SEARCH | Movie Tv/Search CBL/SAT | SHIFT + NETFLIX SEARCH | Shift + Red / Netflix / |
| LISTENI MUSIC REPEAT | Music/Repeat CBL/SAT | SHIFT + APP REPEAT | Shift + Green / APP / |
| GAME RANDOM | Game/Random | SHIFT + YouTube REPEAT A-B | Shift + Yellow / YouTube / |
| STEREO PLAY MODE | Stereo/Play Mode CBL/SAT | SHIFT + Prime Video RANDOM | Shift + Blue / Prime |
| 1 | 1 CBL/SAT | SHIFT + TV 1 | Shift + 1 |
| 2 | 2 CBL/SAT | SHIFT + DVD 2 | Shift + 2 |
| 3 | 3 CBL/SAT | SHIFT + CD-STB 3 | Shift + 3 |
| 4 | 4 CBL/SAT | SHIFT + VIDEO 4 | Shift + 4 |
| 5 | 5 CBL/SAT | SHIFT + TAPE 5 | Shift + 5 |
| 6 | 6 CBL/SAT | SHIFT + TUNER 6 | Shift + 6 |
| 7 | 7 CBL/SAT | SHIFT + AUX-HDD 7 | Shift + 7 |
| 8 | 8 CBL/SAT | SHIFT + USB 8 | Shift + 8 |

| Original | | Replacement | Original | Replacement |
|---|---|---|---|---|
| 9 | 9 CBL/SAT | SHIFT + BLUETOOTH 9 | Shift + 9 | |
| 0/11 | 0/11 CBL/SAT | SHIFT + HDMI - SAT 0 | Shift + 0 | |

| Original | | Replacement | |
|---|---|---|---|
| ON/STANDBY | Power CD | | Power |
| CD | CD | LIST SMART | Smart / List |
| CH DISC | CH/Disc+ CD | CH PAGE | CH+ / Page+ |
| VOL | Vol + Receiver | VOL | Vol + |
| ALBUM | CH/Disc- CD | CH PAGE | CH- / Page- |
| VOL | Vol - Receiver | VOL | Vol - |
| | Up CD | | Up |
| PLAYLIST /CATEGORY | Left CD | | Left |
| ENTER | Enter CD | OK | OK |
| PLAYLIST /CATEGORY | Right CD | | Right |
| SETUP | Setup CD | OPT-TOOLS SETUP | Setup / OPT / |
| | Down CD | | Down |
| RETURN | Return CD | RETURN BACK | Back / Return |
| AUDIO | Audio CD | LANG I/II AUDIO | Audio / Lang I/II |
| | I<< CD | PRESET- | I<< / Preset- |
| | >>I CD | PRESET+ | >>I / Preset+ |
| | << CD | TUNE- | << / Tune- |

| Original | | Replacement | |
|---|---|---|---|
| | Play CD | SLOW | Play / Slow |
| | >> CD | TUNE+ | >> / Tune+ |
| | Pause CD | STEP-FREEZE | Pause / Step / Freeze |
| | Stop CD | HOLD | Stop / Hold |
| MOVIE/TV SEARCH | Search CD | NETFLIX SEARCH | Red / Netflix / Search |
| MUSIC REPEAT | Repeat CD | APP REPEAT | Green / APP / Repeat |
| GAME RANDOM | Random CD | Prime Video RANDOM | Blue / Prime Video / Random |
| STEREO PLAY MODE | Play Mode CD | YouTube REPEAT A-B | Yellow / YouTube / Repeat |
| 1 | 1 CD | TV 1 | 1 |
| 2 | 2 CD | DVD 2 | 2 |
| 3 | 3 CD | CD-STB 3 | 3 |
| 4 | 4 CD | VIDEO 4 | 4 |
| 5 | 5 CD | TAPE 5 | 5 |
| 6 | 6 CD | TUNER 6 | 6 |
| 7 | 7 CD | AUX-HDD 7 | 7 |
| 8 | 8 CD | USB 8 | 8 |
| 9 | 9 CD | BLUETOOTH 9 | 9 |

| Original | | Replacement | | Original | | Replacement |
|---|---|---|---|---|---|---|
| | +10/- - /- - 10/D. Tu Dimmer CD | | Guide / EPG / -/- - | | | |
| | 0/11 CD | | 0 | | | |
| | CLR/Sleep/12 | | Fav / Marker / PC | | | |

| Original | | Replacement | |
|---|---|---|---|
| | Power Receiver Zone 2 | | Power |
| | CH Disc/Album+ Zone 2 | | CH+ / Page+ |
| | Vol + Zone 2 | | Vol + |
| | CH Disc/Album- Zone 2 | | CH- / Page- |
| | Vol - Zone 2 | | Vol - |
| | Up Zone 2 | | Up |
| | Left Zone 2 | | Left |
| | Enter Zone 2 | | OK |
| | Right Zone 2 | | Right |
| | Setup Zone 2 | | Setup / OPT / |
| | Down Zone 2 | | Down |
| | Return Zone 2 | | Back / Return |
| | Audio Zone 2 | | Audio / Lang I/II |
| | I<< Zone 2 | | I<< / Preset- |
| | >>I Zone 2 | | >>I / Preset+ |
| | << Zone 2 | | << / Tune- |
| | Play Zone 2 | | Play / Slow |

| Original | | Replacement | |
|---|---|---|---|
| | >> Zone 2 | | >> / Tune+ |
| | Pause Zone 2 | | Pause / Step / Freeze |
| | Stop Zone 2 | | Stop / Hold |
| | Movie Tv Zone | | Red / Netflix / Search |
| | Music Zone 2 | | Green / APP / Repeat |
| | Game Zone 2 | | Yellow / YouTube / Repeat |
| | Stereo Zone 2 | | Blue / Prime Video / Random |
| | 1 Zone 2 | | 1 |
| | 2 Zone 2 | | 2 |
| | 3 Zone 2 | | 3 |
| | 4 Zone 2 | | 4 |
| | 5 Zone 2 | | 5 |
| | 6 Zone 2 | | 6 |
| | 7 Zone 2 | | 7 |
| | 8 Zone 2 | | 8 |
| | 9 Zone 2 | | 9 |
| | +10/--/--10/D.Tuning Dimmer Zone 2 | | Guide / EPG / -/-- |

| Original | | Replacement | | Original | | Replacement | |
|---|---|---|---|---|---|---|---|
| | 0/11 Zone 2 | | 0 | | | | |
| | CLR/Sleep/12 | | Fav / Marker / PC | | | | |