Original		Replacement	
digital	Digital	MEDIA DISPLAY	Display / Media
theater modes	Yellow/Theater Modes	YouTube REPEAT A-B	Yellow / YouTube / Repeat
	Power		Power
cd	CD	SHIFT + CD-STB 3	Shift + 3
dvd	DVD	SHIFT + DVD 2	Shift + 2
stereo	Green/Stereo	APP REPEAT	Green / APP / Repeat
delay	Blue/Delay	Prime Video RANDOM	Blue / Prime Video / Random
dts	Red/Center	NETFLIX SEARCH	Red / Netflix / Search
up	Up		Up
level	Violet/Level	PC FAV MARKER	Fav / Marker / PC
tape	Tape	SHIFT + TAPE 5	Shift + 5
sat/cab	SAT/CAB	SHIFT + HDMI-SAT 0	Shift + 0
tuner	Tuner	SHIFT + TUNER 6	Shift + 6
video/vcr	Video/VCR	SHIFT + VIDEO 4	Shift + 4
–	Left/-		Left
	OK	OK	OK
+	Right/+		Right

Original		Replacement	
pty rep.	PTY	GOTO TEXT	Text / Goto
down	Down		Down
RDS mix	Menu/RDS	HOME MENU	Menu / Home
	Vol +	VOL +	Vol +
pr+	PR+	CH PAGE +	CH+ / Page+
	Vol -	VOL –	Vol -
pr–	PR-	CH PAGE –	CH- / Page-
	Mute	DIMMER MUTE	Mute / Dimmer
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX-HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9

Original	Replacement	Original	Replacement
memo Memo	LIST SMART Smart / List		
0 0	HDMI - SAT 0 0		

Original		Replacement	
digital	Digital	MEDIA DISPLAY	Display / Media
theater modes	Yellow/Theater Modes	YouTube REPEAT A-B	Yellow / YouTube / Repeat
	Power		Power
cd	CD	SHIFT + CD-STB 3	Shift + 3
dvd	DVD	SHIFT + DVD 2	Shift + 2
stereo	Green/Stereo	APP REPEAT	Green / APP / Repeat
delay	Blue/Delay	Prime Video RANDOM	Blue / Prime Video / Random
dts	Red/Center	NETFLIX SEARCH	Red / Netflix / Search
up	Up		Up
level	Violet/Level	PC FAV MARKER	Fav / Marker / PC
tape	Tape	SHIFT + TAPE 5	Shift + 5
sat/cab	SAT/CAB	SHIFT + HDMI-SAT 0	Shift + 0
tuner	Tuner	SHIFT + TUNER 6	Shift + 6
video/vcr	Video/VCR	SHIFT + VIDEO 4	Shift + 4
–	Left/-		Left
ok	OK	OK	OK
+	Right/+		Right

Original		Replacement	
down	Down		Down
RDS mix	Menu/RDS	HOME MENU	Menu / Home
	Vol +	VOL +	Vol +
pr+	PR+/ >>I	PRESET+	>>I / Preset+
pr+	PR+/ >>I	CH PAGE +	CH+ / Page+
	Vol -	VOL –	Vol -
pr–	PR-/ I<<	PRESET-	I<< / Preset-
pr–	PR-/ I<<	CH PAGE –	CH- / Page-
	Mute	DIMMER MUTE	Mute / Dimmer
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX-HDD 7	7
8	8	USB 8	8

Original		Replacement	
9	9	BLUETOOTH 9	9
memo	Memo	LIST SMART	Smart / List
0	0	HDMI - SAT 0	0
REV	<<	TUNE-	<< / Tune-
PLAY	Play	SLOW	Play / Slow
FWD	>>	TUNE+	>> / Tune+
DISC REC vcr	Rec	REC MODE	Rec / Rec Mode
STOP	Stop	HOLD	Stop / Hold
PAUSE	Pause	STEP-FREEZE	Pause / Step / Freeze

Original	Replacement

Original		Replacement		Original		Replacement	
digital	Digital	MEDIA DISPLAY	Display / Media	pty rep.	PTY	GOTO TEXT	Text / Goto
theater modes	Yellow/Theater Mo	YouTube REPEAT A-B	Yellow / YouTube / Repeat	down	Down		Down
	Power		Power	RDS mix	Menu/RDS	HOME MENU	Menu / Home
cd	CD	SHIFT + CD - STB 3	Shift + 3		Vol +	+ VOL	Vol +
dvd	DVD	SHIFT + DVD 2	Shift + 2	pr+	PR+/ >>I	+ CH PAGE	CH+ / Page+
stereo	Green/Stereo	APP REPEAT	Green / APP / Repeat		Vol -	VOL –	Vol -
delay	Blue/Delay	Prime Video RANDOM	Blue / Prime Video / Random	pr–	PR-/I <<	CH PAGE –	CH- / Page-
dts	Red/Center	NETFLIX SEARCH	Red / Netflix / Search		Mute	DIMMER MUTE	Mute / Dimmer
up	Up		Up	1	1	TV 1	1
level	Violet/Level	PC FAV MARKER	Fav / Marker / PC	2	2	DVD 2	2
tape	Tape	SHIFT + TAPE 5	Shift + 5	3	3	CD - STB 3	3
sat/cab	SAT/CAB	SHIFT + HDMI - SAT 0	Shift + 0	4	4	VIDEO 4	4
tuner	Tuner	SHIFT + TUNER 6	Shift + 6	5	5	TAPE 5	5
video /vcr	Video/VCR	SHIFT + VIDEO 4	Shift + 4	6	6	TUNER 6	6
–	Left/-		Left	7	7	AUX - HDD 7	7
ok	OK	OK	OK	8	8	USB 8	8
+	Right/+		Right	9	9	BLUETOOTH 9	9

Original		Replacement		Original		Replacement	
memo	Memo	LIST SMART	Smart / List				
0	0	HDMI - SAT 0	0				
REV	<<	TUNE-	<< / Tune-				
PLAY	Play	SLOW	Play / Slow				
FWD	>>	TUNE+	>> / Tune+				
DISC REC vcr	Rec	REC MODE	Rec / Rec Mode				
STOP	Stop	HOLD	Stop / Hold				
PAUSE	Pause	STEP - FREEZE	Pause / Step / Freeze				

Original		Replacement		Original		Replacement	
digital	Digital	MEDIA DISPLAY	Display / Media	+	Right / +		Right
theater modes	Yellow/Theater Modes	YouTube REPEAT A-B	Yellow / YouTube / Repeat	pty rep.	PTY	GOTO TEXT	Text / Goto
	Power		Power	down	Down		Down
cd	CD	SHIFT + CD - STB 3	Shift + 3	RDS mix	Menu/RDS	HOME MENU	Menu / Home
dvd	DVD	SHIFT + DVD 2	Shift + 2	RDS mix	Menu/RDS	RDS AV INPUT	AV / Input / RDS
stereo	Green/Stereo	APP REPEAT	Green / APP / Repeat	+	Vol +	+ VOL	Vol +
delay	Blue/Delay	Prime Video RANDOM	Blue / Prime Video / Random	pr+	PR+/ >>I	+ CH PAGE	CH+ / Page+
dts	Red/Center	LANG I/II AUDIO	Audio / Lang I/II	pr+	PR+/ >>I	PRESET+	>>I / Preset+
dts	Red/Center	NETFLIX SEARCH	Red / Netflix / Search	–	Vol -	VOL –	Vol -
up	Up		Up	pr–	PR-/ I<<	CH PAGE –	CH- / Page-
level	Violet/Level	PC FAV MARKER	Fav / Marker / PC	pr–	PR-/ I<<	PRESET-	I<< / Preset-
tape	Tape	SHIFT + TAPE 5	Shift + 5		Mute	DIMMER MUTE	Mute / Dimmer
sat/cab	SAT/CAB	SHIFT + HDMI - SAT 0	Shift + 0	1	1	TV 1	1
tuner	Tuner	SHIFT + TUNER 6	Shift + 6	2	2	DVD 2	2
video /vcr	Video/VCR	SHIFT + VIDEO 4	Shift + 4	3	3	CD - STB 3	3
–	Left/-		Left	4	4	VIDEO 4	4
ok	OK	OK	OK	5	5	TAPE 5	5

Original		Replacement	
6	6	TUNER 6	6
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
memo	Memo	LIST SMART	Smart / List
0	0	HDMI - SAT 0	0
REV	<<	TUNE-	<< / Tune-
PLAY	Play	SLOW	Play / Slow
FWD	>>	TUNE+	>> / Tune+
DISC REC vcr	Rec	REC MODE	Rec / Rec Mode
STOP	Stop	HOLD	Stop / Hold
PAUSE	Pause	STEP - FREEZE	Pause / Step / Freeze

Original	Replacement