Original		Replacement	
	Power		Power
	Mute	MUTE	Mute
	V-Format	PICTURE FORMAT	Format
	Sleep	PROG SLEEP	Sleep
	Text	REPEAT TEXT	Text
	TV / Radio	SEARCH TV/R	TV/R
	Red	A	Red
	Green	B	Green
	Yellow	C	Yellow
	Speaker	SOUND DUAL	Dual
	Subtitle	AD SUBT	Subt
	Blue	D	Blue
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5

Original		Replacement	
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
	List	DISC NAV LIST	List
	Recall	RETURN BACK	Back
	Menu	TOP MENU MENU	Menu
	Exit	CLEAR EXIT	Exit
	Up		Up
	Left		Left
OK	OK	OK	Ok
	Right		Right
	Down		Down
	Page Down	SHIFT + CH −	Shift + Ch -
	Page Up	SHIFT + CH +	Shift + Ch +
VOL +	Vol +	VOL +	Vol +

Original		Replacement	
VOL –	Vol -	VOL –	Vol -
INFO	Info	DISPLAY INFO	Info
CH	CH+	+ CH	Ch +
CH	CH-	CH –	Ch -
FAV	FAV	FAV PRE-CH	Pre Ch
GUIDE	Guide	GUIDE	Guide
ZOOM	Zoom	ZOOM	Eject
✓	✓	HOME SMART	Smart
▶	Play	PLAY MODE ▶	Play
■	Stop	■	Stop
❚❚	Pause	❚❚	Pause
●	Rec	REC MODE ●	Rec
▸[≡]	▸[≡]	E-MANUAL D.MENU	D. Menu
I>	I>	SHIFT + PLAY MODE ▶	Shift + Play
<<	<<	«	<<
>>	>>	»	>>
SAT	SAT	TIMER AV	AV

Original		Replacement	
>I<	>I<	SHIFT + ■	Shift + Stop
I<<	I<<	«	I<<
>>I	>>I	»	>>I
Picture	Picture	APP MEDIA	Media
Bookmark	Bookmark	SETTINGS OPT	Options
Next Bookmark	Next Bookmark	ECO 3D	3D