Original		Replacement	
	Power		Power
SOURCE	Source	TIMER AV	AV
SPORTS	Sports	APP MEDIA	Media
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
TTX/MIX	TTX/MIX	REPEAT TEXT	Text
PRE-CH	PRE-CH	FAV PRE-CH	Pre Ch
+	Vol+	+ VOL	Vol +
−	Vol-	VOL −	Vol -

Original		Replacement	
MUTE	Mute	MUTE	Mute
P	PR+	+ CH	Ch +
P	PR-	CH −	Ch -
CH LIST	CH.LIST	DISC NAV LIST	List
MENU	Menu	TOP MENU MENU	Menu
SMART HUB	Smart HUB	HOME SMART	Smart
GUIDE	Guide	GUIDE	Guide
TOOLS	Tools	SETTINGS OPT	Options
INFO	Info	DISPLAY INFO	Info
▲	Up	▲	Up
▼	Down	▼	Down
▶	Right	▶	Right
◀	Left	◀	Left
	Enter	OK	Ok
RETURN	Return	RETURN BACK	Back
EXIT	Exit	CLEAR EXIT	Exit
A	Red/A	A	Red

Original		Replacement	
B	Green/B	B	Green
C	Yellow/C	C	Yellow
D	Blue/D	D	Blue
E-MANUAL	E-Manual	SHIFT + E-MANUAL D.MENU	Shift + D. Menu
EXTRA	Extra	E-MANUAL D.MENU	D. Menu
SEARCH	Search	SEARCH TV/R	TV/R
PIC SIZE	PIC.Size	PICTURE FORMAT	Format
PICTURE	Picture	SHIFT + PICTURE FORMAT	Shift + Format
AD/SUBT.	AD/Subt	AD SUBT	Subt
<<|<<	<<|<<	<<	<<
II	Pause	II	Pause
>>|>>|	>>|>>|	>>	>>
●	Rec	REC MODE ●	Rec
▶	Play	PLAY MODE ▶	Play
■	Stop	■	Stop

Original	Replacement