Originalfernbedienung	Ersatzfernbedienung	Originalfernbedienung	Ersatzfernbedienung
System Power	Power	Tape	Shift + 5
System Power Off	Shift + Power	MD	Shift + 4
Source On/Off	Red / Netflix / Search	1 Tuner	1
Source On/Off	Green / APP / Repeat	2 Tuner	2
Source On/Off	Blue / Prime Video / Random	3 Tuner	3
Source On/Off CD	Yellow / YouTube / Repeat	A. F/P Tuner	Guide / EPG / -/--
Source On/Off	Shift + Red / Netflix /	4 Tuner	4
Source On/Off	Shift + Green / APP /	5 Tuner	5
Source On/Off	Shift + Yellow / YouTube /	6 Tuner	6
Source On/Off MD	Shift + Blue / Prime	B. -/-- Tuner	Fav / Marker / PC
Source On/Off	Shift + Fav / Marker / PC	7 Tuner	7
Phono	Shift + 1	8 Tuner	8
CD	Shift + 3	9 Tuner	9
Tuner	Shift + 6	Mode Tuner	Smart / List
CD-R	Shift + 2	- Tuner	CH- / Page-
AUX1	Shift + 7	0 Tuner	0
AUX2	Shift + 8	+ Tuner	CH+ / Page+

Originalfernbedienung		Ersatzfernbedienung		Originalfernbedienung	Ersatzfernbedienung
MEMO	Memo Tuner	MEDIA DISPLAY	Display / Media		
SCROLL	Scroll Tuner	RETURN BACK	Back / Return		
CANCEL	Cancel Tuner	CLEAR EXIT CANCEL	Exit / Cancel / Clear		
1-MODE TEXT	Text / Mode 1	GOTO TEXT	Text / Goto		
MODE-2 TIME	Time/Mode 2	TIMER SLEEP	Sleep / Timer		
I<<	I<< Tuner	PRESET- I<<	I<< / Preset-		
>>I	>>I Tuner	PRESET+ >>I	>>I / Preset+		
MUTE	Mute	DIMMER MUTE	Mute / Dimmer		
<<	<< Tuner	TUNE- <<	<< / Tune-		
>>	>> Tuner	TUNE+ >>	>> / Tune+		
VOLUME	Vol +	+ VOL	Vol +		
VOLUME	Vol -	VOL −	Vol -		

Originalfernbedienung		Ersatzfernbedienung		Originalfernbedienung		Ersatzfernbedienung	
SYSTEM ON	System Power		Power	TAPE	Tape	SHIFT + TAPE 5	Shift + 5
POWER OFF	System Power Off	SHIFT +	Shift + Power	MD	MD	SHIFT + VIDEO 4	Shift + 4
SOURCE ON/OFF	Source On/Off	SHIFT + NETFLIX SEARCH	Shift + Red / Netflix /	1	1 CDR	TV 1	1
SOURCE ON/OFF	Source On/Off	NETFLIX SEARCH	Red / Netflix / Search	2	2 CDR	DVD 2	2
SOURCE ON/OFF	Source On/Off	APP REPEAT	Green / APP / Repeat	3	3 CDR	CD - STB 3	3
SOURCE ON/OFF	Source On/Off CD	YouTube REPEAT A-B	Yellow / YouTube / Repeat	4	4 CDR	VIDEO 4	4
SOURCE ON/OFF	Source On/Off	Prime Video RANDOM	Blue / Prime Video / Random	5	5 CDR	TAPE 5	5
SOURCE ON/OFF	Source On/Off	SHIFT + APP REPEAT	Shift + Green / APP /	6	6 CDR	TUNER 6	6
SOURCE ON/OFF	Source On/Off	SHIFT + YouTube REPEAT A-B	Shift + Yellow / YouTube /	7	7 CDR	AUX - HDD 7	7
SOURCE ON/OFF	Source On/Off MD	SHIFT + Prime Video RANDOM	Shift + Blue / Prime	8	8 CDR	USB 8	8
SOURCE ON/OFF	Source On/Off	SHIFT + PC FAV MARKER	Shift + Fav / Marker / PC	9	9 CDR	BLUETOOTH 9	9
PHONO	Phono	SHIFT + TV 1	Shift + 1	MODE	Mode CDR	LIST SMART	Smart / List
CD	CD	SHIFT + CD - STB 3	Shift + 3	-	- CDR	CH PAGE -	CH- / Page-
TUNER	Tuner	SHIFT + TUNER 6	Shift + 6	0	0 CDR	HDMI - SAT 0	0
CD-R	CD-R	SHIFT + DVD 2	Shift + 2	+	+ CDR	CH PAGE +	CH+ / Page+
AUX 1	AUX1	SHIFT + AUX - HDD 7	Shift + 7	MEMO	Memo CDR	MEDIA DISPLAY	Display / Media
AUX 2	AUX2	SHIFT + USB 8	Shift + 8	SCROLL	Scroll CDR	RETURN BACK	Back / Return

Originalfernbedienung		Ersatzfernbedienung		Originalfernbedienung	Ersatzfernbedienung
CANCEL	Cancel CDR	CLEAR EXIT CANCEL	Exit / Cancel / Clear		
1-MOD TEXT	Text / Mode 1	GOTO TEXT	Text / Goto		
ODE-2 TIME	Time / Mode 2	TIMER SLEEP	Sleep / Timer		
I<<	I << CDR	PRESET-	I << / Preset-		
▶	Play CDR	SLOW ▶	Play / Slow		
▶▶I	>>I CDR	PRESET+ ▶▶I	>>I / Preset+		
MUTE	Mute	DIMMER MUTE	Mute / Dimmer		
◀◀	<< CDR	TUNE- ◀◀	<< / Tune-		
■	Stop CDR	HOLD ■	Stop / Hold		
▶▶	>> CDR	TUNE+ ▶▶	>> / Tune+		
▲ VOLUME	Vol +	+ VOL	Vol +		
II	Pause CDR	STEP-FREEZE II	Pause / Step / Freeze		
OPEN/ CLOSE	Open/Close	SURROUND ⏏	Eject / Surround		
VOLUME ▼	Vol -	VOL −	Vol -		

Originalfernbedienung	Ersatzfernbedienung
System Power	Power
System Power Off	Shift + Power
Source On/Off	Shift + Yellow / YouTube /
Source On/Off	Red / Netflix / Search
Source On/Off	Green / APP / Repeat
Source On/Off CD	Yellow / YouTube / Repeat
Source On/Off	Blue / Prime Video / Random
Source On/Off	Shift + Red / Netflix /
Source On/Off	Shift + Green / APP /
Source On/Off MD	Shift + Blue / Prime
Source On/Off	Shift + Fav / Marker / PC
Phono	Shift + 1
CD	Shift + 3
Tuner	Shift + 6
CD-R	Shift + 2
AUX1	Shift + 7
AUX2	Shift + 8

Originalfernbedienung	Ersatzfernbedienung
Tape	Shift + 5
MD	Shift + 4
1 Tape	1
2 Tape	2
3 Tape	3
A. F/P Tape	Guide / EPG / -/--
4 Tape	4
5 Tape	5
6 Tape	6
B. -/-- Tape	Fav / Marker / PC
7 Tape	7
8 Tape	8
9 Tape	9
Mode Tape	Smart / List
- Tape	CH- / Page-
0 Tape	0
+ Tape	CH+ / Page+

Originalfernbedienung		Ersatzfernbedienung		Originalfernbedienung	Ersatzfernbedienung
MEMO	Memo Tape	MEDIA DISPLAY	Display / Media		
CANCEL	Cancel Tape	CLEAR EXIT CANCEL	Exit / Cancel / Clear		
1-MODE TEXT	Text / Mode 1	GOTO TEXT	Text / Goto		
MODE-2 TIME	Time / Mode 2	TIMER SLEEP	Sleep / Timer		
⏮	I << Tape	PRESET- ⏮	I << / Preset-		
▶	Play Tape	SLOW ▶	Play / Slow		
⏭	>>I Tape	PRESET+ ⏭	>>I / Preset+		
MUTE	Mute	DIMMER MUTE	Mute / Dimmer		
◀◀	<< Tape	TUNE- ◀◀	<< / Tune-		
■	Stop Tape	HOLD ■	Stop / Hold		
▶▶	>> Tape	TUNE+ ▶▶	>> / Tune+		
▲ VOLUME	Vol +	+ VOL	Vol +		
◀▶	<> Tape	REC MODE ●	Rec / Rec Mode		
❚❚	Pause Tape	STEP-FREEZE ❚❚	Pause / Step / Freeze		
OPEN/ CLOSE	Open/Close	SURROUND ⏏	Eject / Surround		
VOLUME ▼	Vol -	VOL −	Vol -		

Originalfernbedienung	Ersatzfernbedienung	Originalfernbedienung	Ersatzfernbedienung
System Power	Power	Tape	Shift + 5
System Power Off	Shift + Power	MD	Shift + 4
Source On/Off	Red / Netflix / Search	1 CD	1
Source On/Off CD	Yellow / YouTube / Repeat	2 CD	2
Source On/Off	Green / APP / Repeat	3 CD	3
Source On/Off	Blue / Prime Video / Random	A. F/P CD	Guide / EPG / -/--
Source On/Off	Shift + Red / Netflix /	4 CD	4
Source On/Off	Shift + Green / APP /	5 CD	5
Source On/Off	Shift + Yellow / YouTube /	6 CD	6
Source On/Off MD	Shift + Blue / Prime	B. -/-- CD	Fav / Marker / PC
Source On/Off	Shift + Fav / Marker / PC	7 CD	7
Phono	Shift + 1	8 CD	8
CD	Shift + 3	9 CD	9
Tuner	Shift + 6	Mode CD	Smart / List
CD-R	Shift + 2	- CD	CH- / Page-
AUX1	Shift + 7	0 CD	0
AUX2	Shift + 8	+ CD	CH+ / Page+

Originalfernbedienung		Ersatzfernbedienung		Originalfernbedienung	Ersatzfernbedienung
MEMO	Memo CD	MEDIA DISPLAY	Display / Media		
SCROLL	Scroll CD	RETURN BACK	Back / Return		
CANCEL	Cancel CD	CLEAR EXIT CANCEL	Exit / Cancel / Clear		
1-MODE TEXT	Text / Mode 1 CD	GOTO TEXT	Text / Goto		
MODE-2 TIME	Time / Mode 2 CD	TIMER SLEEP	Sleep / Timer		
I<<	I<< CD	PRESET- I<<	I<< / Preset-		
▶	Play CD	SLOW ▶	Play / Slow		
>>I	>>I CD	PRESET+ >>I	>>I / Preset+		
MUTE	Mute	DIMMER MUTE	Mute / Dimmer		
<<	<< CD	TUNE- <<	<< / Tune-		
■	Stop CD	HOLD ■	Stop / Hold		
>>	>> CD	TUNE+ >>	>> / Tune+		
VOLUME ▲	Vol +	+ VOL	Vol +		
II	Pause CD	STEP-FREEZE II	Pause / Step / Freeze		
OPEN/ CLOSE	Open/Close CD	SURROUND ⏏	Eject / Surround		
VOLUME ▼	Vol -	VOL −	Vol -		