Originalfernbedienung	Ersatzfernbedienung
Power Receiver	Power
Enter Receiver	Ok
Up Receiver	Up
Down Receiver	Down
Right Receiver	Right
Left Receiver	Left
Return Receiver	Back
Q/Setup Receiver	Smart
Home/Audio	Media
Play Receiver	Play
I << Receiver	I <<
>>I Receiver	>>I
<< Receiver	<<
>> Receiver	>>
Pause Receiver	Pause
Stop Receiver	Stop
1 Receiver	1

Originalfernbedienung	Ersatzfernbedienung
2 Receiver	2
3 Receiver	3
4 Receiver	4
5 Receiver	5
6 Receiver	6
7 Receiver	7
8 Receiver	8
9 Receiver	9
0/11 Receiver	0
+10/--/--10/Dimmer/D.Tun Receiver	Shift + Guide
CLR/Sleep/12 Receiver	Pre Ch
Movie Tv/Red/Search	Red
Music/Green/Repeat Receiver	Green
Game/Yellow/Random Receiver	Yellow
Stereo/Blue/Mode Receiver	Blue
Vol + Receiver	Vol +
Vol - Receiver	Vol -

Originalfernbedienung	Ersatzfernbedienung
CH Disc/Album+ Receiver	Ch +
CH Disc/Album- Receiver	Ch -
Power Tv	Shift + Power
Input Tv	AV
CH+ Tv	Shift + Ch +
CH- Tv	Shift + Ch -
Up Tv	Shift + Up
Enter Tv	Shift + Ok
Down Tv	Shift + Down
Right Tv	Shift + Right
Left Tv	Shift + Left
Menu/Prev CH	Menu
Top Menu/Guide	Shift + Menu
Return Tv	Shift + Back
Q/Setup Tv	Shift + Smart
Red Tv	Options
Green Tv	Dual

Originalfernbedienung	Ersatzfernbedienung
Yellow Tv	Subt
Blue Tv	TV/R
1 Tv	Shift + 1
2 Tv	Shift + 2
3 Tv	Shift + 3
4 Tv	Shift + 4
5 Tv	Shift + 5
6 Tv	Shift + 6
7 Tv	Shift + 7
8 Tv	Shift + 8
9 Tv	Shift + 9
0/11 Tv	Shift + 0
+10/--/--10 Tv	Guide
CLR/Sleep/12	Shift + Pre Ch
Vol + Tv	Shift + Dual
Vol - Tv	Shift + Options
AUX	Text

Originalfernbedienung		Ersatzfernbedienung		Originalfernbedienung	Ersatzfernbedienung
TV/CD	TV/ CD	PICTURE FORMAT	Format		
CBL/SAT	CBL/ SAT	ECO 3D	3D		
FM	FM	SHIFT + AD SUBT	Shift + Subt		
NET	NET	SHIFT + APP MEDIA	Shift + Media		
PC	PC	SHIFT + SEARCH TV/R	Shift + TV/ R		
BD/DVD	BD/ DVD	SHIFT + REPEAT TEXT	Shift + Text		
USB	USB	SHIFT + TIMER AV	Shift + AV		

Originalfernbedienung		Ersatzfernbedienung	
SOURCE	Power BD/DVD		Power
MENU PREV CH	Menu/Prev CH	TOP MENU MENU	Menu
TOP MENU GUIDE	Top Menu/Guide BD/DVD	SETTINGS OPT	Options
Q SETUP	Q/Setup	HOME SMART	Smart
RETURN	Return BD/DVD	RETURN BACK	Back
AUDIO HOME	Home/Audio	APP MEDIA	Media
ENTER	Enter BD/DVD	OK	Ok
	Up BD/DVD		Up
	Down BD/DVD		Down
	Right BD/DVD		Right
	Left BD/DVD		Left
	I << BD/DVD		I <<
	>>I BD/DVD		>>I
	<< BD/DVD		<<
	>> BD/DVD		>>
PLAY	Play BD/DVD	PLAY MODE	Play
	Pause BD/DVD		Pause

Originalfernbedienung		Ersatzfernbedienung	
	Stop BD/DVD		Stop
SEARCH MOVIE/TV A	Movie Tv/Red/Search	A	Red
REPEAT MUSIC B	Music/Green/Repeat BD/DVD	B	Green
RANDOM GAME C	Game/Yellow/Random BD/DVD	C	Yellow
MODE STEREO D	Stereo/Blue/Mode BD/DVD	D	Blue
1	1 BD/DVD	1	1
2	2 BD/DVD	2	2
3	3 BD/DVD	3	3
4	4 BD/DVD	4	4
5	5 BD/DVD	5	5
6	6 BD/DVD	6	6
7	7 BD/DVD	7	7
8	8 BD/DVD	8	8
9	9 BD/DVD	9	9
0 11	0/11 BD/DVD	0	0
D.TUN +10 DIMMER	+10/--/--10/D.Tun Dimmer BD/DVD	GUIDE	Guide
CLR SLEEP 12	CLR/Sleep/12	FAV PRE-CH	Pre Ch

BD/DVD

Originalfernbedienung	Ersatzfernbedienung
CBL/ SAT	Text
Vol + Receiver	Vol +
Vol - Receiver	Vol -
Power CBL/ SAT	Shift + Power
CH Disc/ Album+ CBL/ SAT	Ch +
CH Disc/ Album- CBL/ SAT	Ch -
Menu/ Prev CH CBL/ SAT	Shift + Menu
Top Menu/ Guide CBL/ SAT	Shift + Options
Return CBL/ SAT	Shift + Back
Q/ Setup	Shift + Smart
Up CBL/ SAT	Shift + Up
Enter CBL/ SAT	Shift + Ok
Down CBL/ SAT	Shift + Down
Right CBL/ SAT	Shift + Right
Left CBL/ SAT	Shift + Left
Pause CBL/ SAT	Shift + Pause
Stop CBL/ SAT	Shift + Stop

Originalfernbedienung	Ersatzfernbedienung
<< CBL/ SAT	Shift + Ch -
>> CBL/ SAT	Shift + Ch +
Play CBL/ SAT	3D
Movie Tv/ Red/ Search	Dual
Music/ Green/ Repeat CBL/ SAT	Subt
Game/ Yellow/ Random CBL/ SAT	AV
Stereo/ Blue/ Mode CBL/ SAT	Format
1 CBL/ SAT	Shift + 1
2 CBL/ SAT	Shift + 2
3 CBL/ SAT	Shift + 3
4 CBL/ SAT	Shift + 4
5 CBL/ SAT	Shift + 5
6 CBL/ SAT	Shift + 6
7 CBL/ SAT	Shift + 7
8 CBL/ SAT	Shift + 8
9 CBL/ SAT	Shift + 9
0/ 11 CBL/ SAT	Shift + 0

Originalfernbedienung	Ersatzfernbedienung	Originalfernbedienung	Ersatzfernbedienung
BD/DVD BD/ DVD	SEARCH TV/R TV/ R		

Originalfernbedienung		Ersatzfernbedienung	
SOURCE	Power TV/ CD		Power
CH DISC +	CH/ Disc+ TV/ CD	CH +	Ch +
ALBUM −	CH/ Disc TV/ CD	CH −	Ch -
RETURN	Return TV/ CD	RETURN BACK	Back
Q SETUP	Q/ Setup TV/ CD	HOME SMART	Smart
AUDIO HOME	Home/ Audio	APP MEDIA	Media
	Up TV/ CD		Up
	Down TV/ CD		Down
	Right TV/ CD		Right
	Left TV/ CD		Left
ENTER	Enter TV/ CD	OK	Ok
	I << TV/ CD		I <<
	>>I TV/ CD		>>I
	<< TV/ CD		<<
	>> TV/ CD		>>
PLAY	Play TV/ CD	PLAY MODE	Play
	Pause TV/ CD		Pause

Originalfernbedienung		Ersatzfernbedienung	
	Stop TV/ CD		Stop
SEARCH MOVIE/TV A	Movie Tv/ Red/ Search	A	Red
REPEAT MUSIC B	Music/ Green/ Repeat TV/ CD	B	Green
RANDOM GAME C	Game/ Yellow/ Random TV/ CD	C	Yellow
MODE STEREO D	Stereo/ Blue/ Mode TV/ CD	D	Blue
1	1 TV/ CD	1	1
2	2 TV/ CD	2	2
3	3 TV/ CD	3	3
4	4 TV/ CD	4	4
5	5 TV/ CD	5	5
6	6 TV/ CD	6	6
7	7 TV/ CD	7	7
8	8 TV/ CD	8	8
9	9 TV/ CD	9	9
0 11	0/ 11 TV/ CD	0	0
D.TUN +10 DIMMER	+10/ - - / - - 10/ D. Tun Dimmer TV/ CD	GUIDE	Guide
CLR SLEEP 12	CLR/ Sleep/ 12	FAV PRE-CH	Pre Ch

TV/ CD

Originalfernbedienung		Ersatzfernbedienung	
VOL	Vol + Recei ver	+ VOL	Vol +
VOL	Vol - Recei ver	VOL –	Vol -
TV/CD	TV/ CD	SEARCH TV/R	TV/ R

Originalfernbedienung	Ersatzfernbedienung

Originalfernbedienung		Ersatzfernbedienung	
RECEIVER	Power Receiver Zone 2		Power
VOL	Vol + Zone 2	+ VOL	Vol +
VOL	Vol - Zone 2	VOL −	Vol -
CH DISC	CH Disc/Album+ Zone 2	+ CH	Ch +
ALBUM	CH Disc/Album- Zone 2	CH −	Ch -
	Up Zone 2		Up
ENTER	Enter Zone 2	OK	Ok
	Down Zone 2		Down
	Right Zone 2		Right
	Left Zone 2		Left
RETURN	Return Zone 2	RETURN BACK	Back
Q SETUP	Q/Setup Zone 2	HOME SMART	Smart
AUDIO HOME	Home/Audio Zone	APP MEDIA	Media
	I << Zone 2		I <<
	>>I Zone 2		>>I
PLAY	Play Zone 2	PLAY MODE	Play
	>> Zone 2		>>

Originalfernbedienung		Ersatzfernbedienung	
	<< Zone 2		<<
	Pause Zone 2		Pause
	Stop Zone 2		Stop
SEARCH MOVIE/TV A	Movie Tv/Red/Search	A	Red
REPEAT MUSIC B	Music/Green/Repeat Zone 2	B	Green
RANDOM GAME C	Game/Yellow/Random Zone 2	C	Yellow
MODE STEREO D	Stereo/Blue/Mode Zone 2	D	Blue
1	1 Zone 2	1	1
2	2 Zone 2	2	2
3	3 Zone 2	3	3
4	4 Zone 2	4	4
5	5 Zone 2	5	5
6	6 Zone 2	6	6
7	7 Zone 2	7	7
8	8 Zone 2	8	8
9	9 Zone 2	9	9
0 11	0/11 Zone 2	0	0

Originalfernbedienung	Ersatzfernbedienung	Originalfernbedienung	Ersatzfernbedienung
+10/ - - / - - 10/ D. Tu Di mmer Zone 2	Gui de		
CLR/ Sl eep/ 12	Pr e Ch		